



JMA DAS Platform Master Unit Installation Guide

Document Version: 1

Date: April 2023



Legal Notices

Copyright © 2023 John Mezzalingua Associates, LLC dba JMA Wireless. All rights reserved.

This document may contain confidential and/or proprietary information. All company names, brands, and logos are trademarks™ of holders JMA Wireless or its affiliates. All specifications are subject to change without notice.

World Headquarters

JMA Wireless

140 Cortland Ave.

Syracuse, NY 13202 USA

+1-888-201-6073

customerservice@jmawireless.com

For additional contact information, see the JMA Wireless website:

jmawireless.com

Table of Contents

1 - Overview of the JMA DAS Platform	6
1.1 - About this guide	6
1.2 - What Is New	7
2 - Components	8
2.1 - Signal Source Interfaces	10
2.1.1 - TCPRIPOI	10
2.1.2 - TDTPOI	11
2.1.3 - TAPOI	14
2.1.4 - TLPPOI	15
2.1.5 - TDPX	16
2.1.6 - TDFE	17
2.2 - Capacity management	19
2.2.1 - TCM3-4 Capacity Manager Matrix (3x4)	19
2.2.2 - TSW4 Configurable RF Switch	20
2.3 - RF Distribution, Filtering, and Time Synchronization	21
2.3.1 - Splitter/Combiner	21
2.3.2 - Multiplexers	22
2.3.3 - Master Band Combiners	28
2.3.4 - TDD Synchronizer and Reference Module	30
2.4 - Optical Interfaces	31
2.4.1 - TTR Plug-in Optical Modules	31
2.4.2 - ED35TD	36
2.4.3 - Point-to-Point Link	38
2.5 - Coverage Extension and Capacity Distribution	42
2.5.1 - TSFE	42
2.6 - Control and Management	44
2.6.1 - TSPV	44
2.6.2 - TEA-I16	46
2.7 - Power Supply	47
2.7.1 - TPSU/AC and TPSU/48	47
2.7.2 - SUB-PSUN-MU and SUB-PSUN-MU/48	49
2.7.3 - Remote Power Supply Distributor	52
2.8 - Sub-racks for the Installation of Plug-in Components	56
2.9 - Forced-air Cooling Unit	58
3 - Procedures	59
3.1 - Installation	60

3.1.1 - Installation Site Requirements	60
3.1.2 - Precaution and Warning Statements	60
3.1.3 - Installing Master Unit Rack-mount Components	62
3.1.4 - Positioning and Installing Master Unit Plug-in Modules	64
3.2 - Connections	66
3.2.1 - Precaution and Warning Statements	66
3.2.2 - RF Connections	67
3.2.3 - RS485 Connections	68
3.2.4 - Optical Connections	70
3.2.5 - Connecting TCPRIPOs to the XLAN Server	74
3.2.6 - Internal DC Power Supply Connections	77
3.2.7 - Connecting External AC Power	78
3.2.8 - Connecting External DC Power	81
3.2.9 - External Alarms Connection	86
3.3 - Power-up	87
3.4 - Configuration and Management	87
3.5 - Preventive Maintenance	88
3.5.1 - Optical Fiber	88
3.5.2 - Optical Connectors	88
3.6 - Replacement Instructions	90
3.6.1 - Replacing Faulty Plug-in Modules	90
3.6.2 - Replacing the ED35TD Fan Unit	91
3.6.3 - Replacing the TDFE Fan Kit	93
3.6.4 - Replacing Faulty TPSU/AC-30-1K and TPSU/48-30-1K	95
3.6.5 - Replacing Faulty TRPSU/AC-58-1.2k and TRPSU/48-58-2k	96
4 - Compliance with the Technical Regulatory Standards	98
4.1 - Compliance with the EU and UK Regulatory Requirements	98
4.1.1 - EU Directive 2014/53/EU – RED (Radio Equipment Directive) and Radio Equipment Regulations 2017 (S.I. 2017/1206)	98
4.1.2 - EU Directive 2015/863/EU – RoHS (Restriction of the Use of certain Hazardous Substances)	100
4.1.3 - EU Directive 2012/19/EU – WEEE (Waste Electrical and Electronic Equipment)	100
4.1.4 - Packaging and Packaging Waste Directive 94/62/EC and subsequent amendments	100
4.2 - Compliance with FCC Rules and Regulations	101
4.2.1 - Radio Equipment Operating Frequency Bands: Commercial Bands	102
4.3 - Industry Canada Compliance	103
5 - Attachments	106
5.1 - Getting Help: Technical Support Contact Information	106
5.2 - Technical Specifications	107

5.3 - Safety Rules	108
5.3.1 - Annex	110
5.4 - Warnings and Caution Statements	112
5.5 - Règles de sécurité	117
5.6 - Mises en garde et déclarations de précaution	122
5.7 - Symbols and Manufacture Labels Affixed to the Product	127
Abbreviations	129

1 - Overview of the JMA DAS Platform

JMA DAS Platform is a multi-band, multi-operator architecture that provides a wide range of flexible and reliable solutions for cellular coverage and capacity distribution. The components of the JMA Platform can be assembled to configure optical DAS, RF repeaters, and integrated solutions.

Optical DAS

Each Optical DAS is made up of two main elements, master unit and remote units, connected via single mode optical fiber to distribute multiple frequency bands and multiple Carriers/MNOs to each remote unit, or multiple remote units to configure multipath (e.g. MIMO) configurations.

The **master unit** is a rack-based modular platform that allows configurations for different needs and a future-proof design. It is connected to the signal source and hosts the supervision unit for the management of the entire DAS.

Remote units (RUs) are distributed throughout the territory to be served. RUs are self-contained and provide signal distribution to a range of both indoor and outdoor antennas. A single master unit supports all classes of RUs, from low power to ultra high power.

RF Repeater

The master unit can be configured for RF repeater applications which do not involve fiber links. JMA RF repeaters can be set up combining Donor Front Ends (TDFE) and service front-ends (TSFE). Up to four Donor Front Ends can be connected to a single Service Front End to provide a single-band, four-operator off-air repeater.

No physical connections are required between the RF repeaters and the cellular network: RF repeaters use a directional antenna as interface to the operator's donor BS and one or more service antennas to transmit the amplified wireless signal to the area to be covered.

When RF repeaters do not provide satisfactory coverage (extensive areas, long tunnels), they can be used along with an optical DAS.

1.1 - About this guide

Due to the increasing number of the JMA DAS Platform components, the information contained in the *DAS Platform Technical Handbook* has been divided into three documents:

- *JMA DAS Platform Master Unit Installation Guide.*
- *JMA DAS Platform Remote Units Installation Guide.*
- *JMA DAS Platform Next Generation Remote Units Installation Guide.*

This document, *JMA DAS Platform Master Unit Installation Guide*, describes the DAS Platform master unit. The **Components** section includes descriptions of the physical interfaces of all the components of the rack-based modular master unit.

The **Procedures** section provides instructions to safely install, connect, power up, and perform preventive maintenance and replacement of the master unit components.

1.2 - What Is New

- New components added to the guide:
 - ED35TD, optical interface between the master unit and next generation remote units. See ["ED35TD" on page 36](#).
 - TSYNC-C, new model of TDD Synchronizer and Reference Module. See ["TDD Synchronizer and Reference Module" on page 30](#).
 - TSPV-NBB, new model of supervision module for control and management of an entire DAS, which includes next generation remote units. See ["TSPV" on page 44](#).
- Modified the recommended gauge of the DC power supply cord to connect external DC power to the TPSU/48 module. See ["Connecting DC Power to the Master Unit Power Supply Components" on page 83](#).
- Added description of the heat shrink tubing applied to RF and sync cables. See [page 67](#) for details.

2 - Components

This section provides detailed descriptions of the JMA DAS Platform components. The components are grouped into the following categories, based on their function:

- **Signal source interfaces: Points of Interface**
 - TCPRIOI – CPRI Point of Interface. See [page 10](#).
 - TDTPOI – DAS Tray Point of Interface. See [page 11](#).
 - TAPOI – Active Point of Interface. See [page 14](#).
 - TLPPOI – Low Power Point of Interface. See [page 15](#).
 - TDPX – MIMO Passive Duplexer. See [page 16](#).
 - TDFE – Digital Donor Front End. See [page 17](#).
- **Capacity Management**
 - TCM3-4 Capacity Manager Matrix (3x4). See [page 19](#).
 - TSW4 Configurable RF Switch. See [page 20](#).
- **RF Distribution, Filtering, and Time Synchronization**
 - Splitter/Combiner. See [page 21](#).
 - Multiplexers. See [page 22](#).
 - Master Band Combiners. See [page 28](#).
 - TDD Synchronizer and Reference Module. See [page 30](#).
- **Optical Interfaces**
 - TTRU1W-S-M, TTRU2W-S-M, TTRU4W-S-M – Optical transceivers. See [page 31](#).
 - TTRX24W-S-M – Ultra-wide band, MIMO 2x2 optical transceiver. See [page 34](#).
 - TTRU2W-S-M-C2 – Optical transceiver for JMA cascade solutions. See [page 33](#).
 - ED35TD – Ultra-wide band, MIMO 2x2 optical transceiver, providing the optical interface towards next generation MIMO remote units. See [page 36](#).
 - Point-to-Point Link – Optical point to point link between TTRUPTPMx (Master P2P module) and TTRUPTPSx (Secondary P2P module). See [page 38](#).
- **Coverage extension and capacity distribution**
 - TSFE – Service Front End, master unit rack-mount component. Single-band/multi-operator interface towards a Service Antenna. See [page 42](#).
 - Remote Units – Multi-carrier equipment connected to the master unit optical components and used in optical DAS to distribute wireless signal throughout the area to be covered. For detailed descriptions of remote units refer to the following guides:
 - *JMA DAS Platform Remote Units Installation Guide*.
 - *JMA DAS Platform Next Generation Remote Units Installation Guide*.

2 - Components

▪ **Control and Management**

- **TSPV** – Supervision module for control and management of an entire DAS. See [page 44](#).
- **TEA-I16** – Additional alarm module used to increase the number of supported external alarms. See [page 46](#).

▪ **Power Supply**

- **TPSU/AC and TPSU/48** – Power supply plug-in modules. See [page 47](#).
- **SUB-PSUN-MU and SUB-PSUN-MU/48** – Space efficient AC-to-DC and DC-to-DC power supply units. See [page 49](#).
- **Remote Power Supply Distributor** – Power supply distribution system for the remote powering of JMA 48Vdc remote units with up-to-2W output power. See [page 52](#).

▪ **Sub-racks for the Installation of Plug-in Components**

- **SUB-TRX-PSU5N** – Sub-rack for the installation of active plug-in components. See [page 56](#).
- **SUB-HPOI** – Sub-rack for the installation of plug-in components that do not require power nor management to function. See [page 57](#).

▪ **Rack Cooling**

Forced-air Cooling Unit – TFAN-19-1U-4F-28V. See [page 58](#).

JMA cabinets for indoor and outdoor installation of the DAS sub-racks are also available.

2.1 - Signal Source Interfaces

2.1.1 - TCPRIPOI


CPRI Point of Interface

The CPRI Point of Interface (TCPRIPOI) is the direct interface between the JMA X-RAN system and the JMA DAS (Distributed Antenna System).

The TCPRIPOI consists of two boards:

- The digital board provides the optical interface to the X-RAN Adaptive Baseband Server (ABS).
- The RF board provides the interface to the JMA DAS Platform components.

Front panel description




Procedures

- "Installing Master Unit Rack-mount Components" on page 62
- "Positioning and Installing Master Unit Plug-in Modules" on page 64
- "RF Connections" on page 67
- "Connecting TCPRIPOIs to the X-RAN Server" on page 74

2.1.2 - TDTPOI


DAS Tray Point of Interface

▪ TDTPOI for FDD applications - Front panel description




2 - Components

TDTPOI (FDD) - Block Diagram



TDTPOI for TDD applications: TDTPOI-25-D and TDTPOI-25-D-LL Additional Ports Description


The following figure describes the additional ports on the DAS Trays for LTE-TDD technology that pick up the TDD reference signals from the BS.



2 - Components

TDTPOI-35x-D and TDTPOI-35x-D-LL: Front Panel Description

The TDTPOI-35x-D and TDTPOI-35x-D-LL modules provide the RF interface towards mid-band MIMO base stations.



Procedures

"Positioning and Installing Master Unit Plug-in Modules" on page 64

"RF Connections" on page 67

2.1.3 - TAPOI

Active Point of Interface

The JMA active Point of Interface is a flexible band specific and service provider specific RF interface that accepts either a simplex or a duplex feed.

▪ **Front Panel Description**

Led ON: TAPOI operating status

Off	module switched off
Green	power supply is present

Led ALM: TAPOI alarm status

Off	no active alarms
Blinking Orange	maximum severity level of active alarms: warning
Orange	maximum severity level of active alarms: minor
Blinking Red	maximum severity level of active alarms: major
Red	maximum severity level of active alarms: critical

BTS DL/UL

Duplex port from/to Base Station or Simplex downlink RF port from Base Station (4.3-10, female connector)

BTS UL

SMA (f) uplink RF output port - to BS

DL OUT


SMA (f) downlink RF output port

UL IN

SMA (f) uplink RF input port



▪ **Block diagram**



▪ **Procedures**

"Positioning and Installing Master Unit Plug-in Modules" on page 64


"RF Connections" on page 67

2.1.4 - TLPPOI

Active Low-power Point of Interface with Additional Gain Stage

JMA low-power Point of Interface modules (TLPPOI) are flexible low-power RF interfaces used in optical DAS to interface one simplex, MIMO 2x2 low-power Base Station.

▪ **Front Panel Description**



▪ **Procedures**

"Positioning and Installing Master Unit Plug-in Modules" on page 64


"RF Connections" on page 67

2.1.5 - TDPX

MIMO Passive Duplexer

JMA MIMO passive duplexers are single-band/single-operator RF interfaces between a duplex, MIMO 2x2, low-power Base Station and Point Of Interface modules with simplex inputs.

Front Panel Description



Procedures

"Positioning and Installing Master Unit Plug-in Modules" on page 64

"RF Connections" on page 67

2.1.6 - TDFE

Donor Front End

The Digital Donor Front End (TDFE) is the off-air JMA RF interface towards a Donor Antenna. No physical connections are required between the DFE and the cellular network: the Donor Antenna provides the connection to a Base Station over an air link.

Front Panel Description

Led ALM: TDFE alarm status


Off	no active alarms
Blinking Orange	maximum severity level of active alarms: warning
Orange	maximum severity level of active alarms: minor
Blinking Red	maximum severity level of active alarms: major
Red	maximum severity level of active alarms: critical

Led ON: TDFE operating status

Off	module switched off
Green	power supply is present

DL

Downlink RF output port (SMA-f connector) - to Service Front End or optical modules



UL

Uplink RF input port (SMA-f connector) - from Service Front End or optical modules

DONOR ANT

Donor Antenna Port (N or 4.3-10, female type)




N type port



4.3-10 type port

2 - Components

▪ Block diagram



Each TDFE module hosts the duplexer, to be connected to the Donor Antenna to separate/combine downlink and uplink paths. In downlink the signal from the Donor Antenna is preamplified by a Low Noise Amplifier and converted into an IF signal by a down converter. The selection of the band of frequencies or channels to be extended is handled by a digital filter.

The digital filter can manage one variable band or two variable sub-bands (standard version). A full-feature version is available to manage up to nine variable sub-bands.

An up converter converts the IF signal into the RF output signal.

In uplink, the signal from the Service Front End or from the optical DAS is converted into an IF signal by a down converter, filtered and re-converted into an RF signal, amplified by a power amplifier and re-transmitted to the signal source.

▪ Procedures

["Positioning and Installing Master Unit Plug-in Modules" on page 64](#)

["RF Connections" on page 67](#)

["Replacement Instructions" on page 90](#)

NOTE: Full-feature TDFEs (TDFE-EGSM-F) must be installed in deep active sub-racks. See [page 57](#).


2.2 - Capacity management

The JMA DAS platform components for capacity management, TCM3-4 and TWS4, provide complete flexibility, enabling the JMA DAS architecture to be designed for reutilization of sectors across the campus or metro areas and support a reduction in head-end eNodeB equipment by up to 25%. As an example, sector remapping can be cycled to balance weekend demands from business week demands.

Transitions are streamlined because these configurations are facilitated via JMA’s OMT (Operation and Maintenance Terminal), minimizing manual intervention and facility visits to enable reuse of capacity


2.2.1 - TCM3-4 Capacity Manager Matrix (3x4)

The following figure describes the ports and LEDs on the TCM3-4.



2.2.2 - TSW4 Configurable RF Switch

The following figure describes the ports and LEDs on the TSW4.



▪ **Procedures**

"Positioning and Installing Master Unit Plug-in Modules" on page 64

"RF Connections" on page 67.

2.3 - RF Distribution, Filtering, and Time Synchronization


2.3.1 - Splitter/Combiner

JMA two-way and four-way splitter/combiner modules can be used to manage either up to four Point of Interface (or TDFE) modules, operating in the same band, or up to four optical modules.


JMA Splitter/Combiner modules can be deployed in TDD systems.

Four-way Combiner/Splitter (TSC4W-U and TSC4W-X) input/output ports

- TSC4W managing up to four POIs or TDFEs operating in the same band




- TSC4W managing up to four optical modules




Two-way Combiner/Splitter (TSC2W-U and TSC2W-X) input/output ports

- TSC2W managing up to two POIs or TDFEs operating in the same band



- TSC2W managing up to two optical modules



2.3.2 - Multiplexers


JMA multiplexers are used to distribute signals in multi-band configurations.

2.3.2.1 - Diplexers

TDIP-LO/HI2325-D-R

The TDIP-LO/HI2325-D-R is the two-port to one-port multiplexer that combines low-band and high-band downlink signals in JMA nine-band on a single layer solution, which serves two co-located remote units (main and add-on).


Input/output ports




TDIP-LOHI/2325-D-R and TDIP-LOHI23/25-D-R

The TDIP-LOHI/2325-D-R and TDIP-LOHI23/25-D-R are the two-port to one-port multiplexers that combine downlink signals, serving two co-located remote units (main and add-on).

TDIP-LOHI/2325-D-R Input/Output Ports



TDIP-LOHI23/25-D-R Input/Output Ports




2.3.2.2 - Triplexers

Different models of triplexers are available. Triplexers with the built-in 1:4 splitter/combiner allow the distribution of RF signals to four optical modules.


FDD/TDD triplexers for LTE-TDD applications combine the FDD/TDD bands and synchronize the downstream DAS components.

- **Triplexers (FDD) without built-in 1:4 Splitter/Combiner**
TRI-x and TMBC-67E8AE - Input/output ports



2 - Components


Triplexers (FDD) with built-in 1:4 Splitter/Combiner TRI-SC4W-x - Input/output ports




Triplexers (FDD/TDD) - Input/output ports

The following figure describes the ports on the triplexers for LTE-TDD applications. The triplexers combine FDD and TDD signals while synchronizing the downstream DAS components.

- TRI-2325TR




- TRI-23T26TR



2.3.2.3 - Pentaplexers and Esaplexers


Input/output ports




2.3.2.4 - Eptaplexers

Two different models of eptaplexers are available to support two different combination of main and add-on remote units.

TEPTA-UW-LH23/25 - Input/output ports




TEPTA-UW-LH/2325 - Input/output ports



2.3.3 - Master Band Combiners


Master Band Combiners distribute the FDD/TDD bands and synchronize the downstream DAS components for Time-Division Long-Term Evolution (LTE-TDD) technology. Different models of Master Band Combiners are available.

▪ **TMBC-LO1925TR, TMBC-19HAWX2325TR, and TMBC-7E19HAWX25TR - Input/output ports**



2 - Components

▪ TMBC-35WTR - Input/output ports



2.3.4 - TDD Synchronizer and Reference Module

The TDD synchronizer manages and distributes the TDD reference signal.

TSYNC, TSYNC-X, and TSYNC-N - Front Panel Description

Led ON: TSYNC operating status

Off	module switched off
Green	power supply is present

Led ALM: TSYNC alarm status

Off	no active alarms
Blinking Orange	maximum severity level of active alarms: warning
Orange	maximum severity level of active alarms: minor
Blinking Red	maximum severity level of active alarms: major
Red	maximum severity level of active alarms: critical

RF TDD REF IN


TDD reference signal input port (SMA-f connector)

RF PILOT OUT (1 to 4)

TDD reference signal output ports (SMA-f connectors) to TDD multiplexers and master band combiners

SYNC OUT (1 to 4)

TDD reference signal output ports (SMB-m connectors) to the TDD Point of Interface modules



TSYNC-C Front Panel Description

Led ON: TSYNC operating status

Off	module switched off
Green	power supply is present

Led ALM: TSYNC alarm status

Off	no active alarms
Blinking Orange	maximum severity level of active alarms: warning
Orange	maximum severity level of active alarms: minor
Blinking Red	maximum severity level of active alarms: major
Red	maximum severity level of active alarms: critical


RF TDD REF IN

TDD reference signal input port (SMA-f connector)

SYNC OUT (1 to 8)

TDD reference signal output ports (SMB-m connectors) to:

- › Up to four TDD Points of Interface
- › Up to four ED35TD optical transceivers



2.4 - Optical Interfaces

The following components provide the optical interface between master unit and remote units allowing the bidirectional transmission of signals over the connecting optical fiber.


2.4.1 - TTR Plug-in Optical Modules

Plug-in optical modules are connected to the remote units via single-mode SMR 9/125 optical fiber. An auto-levelling functionality (AGC) compensates up to 10dB optical link loss in order to guarantee constant gain over different optical budgets. This feature simplifies system installation, makes commissioning quick and easy and avoids field adjustments.

2.4.1.1 - TTRU1W-S-M, TTRU2W-S-M, TTRU4W-S-M

- ▶ **TTRU1W-S-M**, 1: 1 configuration: One optical transmitter and one optical receiver for the management of one remote unit (10dB optical link budget, up to 20km distance - 12.4 miles).
- ▶ **TTRU2W-S-M**, 1:2 configuration: One optical transmitter split by two and two combined optical receivers, for the management of up to two remote units (10dB optical link budget, up to 20km distance- 12.4 miles).
- ▶ **TTRU4W-S-M**, 1:4 configuration: One optical transmitter split by four and four combined optical receivers, for the management of up to four remote units (7dB optical link budget, up to 14km distance - 8.7 miles).


▪ Example: TTRU4W-S-M Block Diagram



2 - Components

Example: TTRU4W-S-M Front Panel Description

The following figure describes the connectors and LEDs on the TTRU4W-S-M optical module (1:4 configuration - WDM).



Procedures

"Positioning and Installing Master Unit Plug-in Modules" on page 64

"Optical Connections" on page 70


2 - Components

2.4.1.2 - TTRU2W-S-M-C2

The TTRU2W-S-M-C2 supports two remote locations. In each remote location main and add-on remote units are connected to the same fiber via an optical splitter (TOPT-SC2).

Front Panel Description

The following figure describes the ports and LEDs on the TTRU2W-S-M-C2 optical module.



Procedures

"Positioning and Installing Master Unit Plug-in Modules" on page 64


"Optical Connections" on page 70

2 - Components

2.4.1.3 - TTRX24W-S-M

The TTRX24W-S-M is the ultra-wide band, MIMO 2x2 optical transceiver, providing the optical interface towards up to two MIMO remote units.


▪ Block Diagram



2 - Components

Front Panel Description

The following figure describes the ports and LEDs on the TTRX24W-S-M optical module.



Procedures

"Positioning and Installing Master Unit Plug-in Modules" on page 64

"Optical Connections" on page 70

2.4.2 - ED35TD

The ED35TD sub-rack is the optical interface between master unit and next generation remote units.

Warning

The ED35TD contains a non-replaceable battery so please observe the following precautions:


- During use, storage or transportation of the equipment, the battery cannot be subjected to extreme conditions, such as:
 - An extremely high temperature surrounding environment.

NOTE: The battery allowable temperature range is -40 to +85 °C.
 - An extremely low air pressure.


Exposing the battery to extreme conditions can result in an explosion or the leakage of flammable liquid or gas.

- Disposal of battery into fire or a hot oven, or mechanically crushing or cutting of the battery can result in an explosion.

ED35TD Front Panel Description



ED35TD Rear Panel Description



2 - Components

▪ ON and ALM LEDs:

ON: ED35TD operating status	
Off	Module switched off
Green	Power supply is present

ALM: ED35TD alarm status	
Off	No active alarms
Blinking Orange	Maximum severity level of active alarms: warning
Orange	Maximum severity level of active alarms: minor
Blinking Red	Maximum severity level of active alarms: major
Red	Maximum severity level of active alarms: critical

▪ LEDs below each optical port:



Green LED: Optical link status	
On	The optical link is operational
Off	The optical link is not able to achieve the operational status

Yellow LED: Alarm status of the remote unit connected to the port	
On	Critical or major alarms active on the connected remote unit
Blinking	Warning or minor alarms active on the connected remote unit
Off	No active alarms on the connected remote unit

▪ Procedures

"Installing Master Unit Rack-mount Components" on page 62

"Optical Connections" on page 70

"Connecting External DC Power" on page 81

"Internal DC Power Supply Connections" on page 77

NOTE: The ED35TD can be connected either to an external DC power source (see "Connecting External DC Power" on page 81), or to the DAS sub-racks providing power supply (see "Internal DC Power Supply Connections" on page 77).

2.4.3 - Point-to-Point Link

The optical point-to-point link between TTRUPTPMx (Master P2P module) and TTRUPTPSx (Secondary P2P module) allows a separation distance -up to 20km- between the master unit and distant optical transceivers, installed in remote sub-racks.


Master P2P modules are installed at the master unit site, then connected, through an optical link, to secondary P2P modules, installed in remote sub-racks. This configuration allows a significant reduction in the number of fibers running over the long distance: with P2P in fact only one fiber per sector is deployed, rather than one fiber per remote unit.

P2P modules perform the RF-to-optical and optical-to-RF conversion allowing the bidirectional transmission of signals over the connecting optical fiber (single-mode SMR 9/125).

2.4.3.1 - Master Point-to-Point module

Master Point to Point modules are installed at the master unit site.


▪ **Block Diagram**



2 - Components

▪ Front Panel Description

The following figure describes the ports and LEDs on the Master P2P module.



2.4.3.2 - Secondary Point-to-Point Modules

The secondary P2P modules are installed in remote sub-racks. Secondary P2P modules include a built-in supervision unit that controls the remote sub-rack with all connected remote units, and, when equipped, the power supply sub-rack (SUB-PSUN-MU or SUB-PSUN-MU/48).

The DAS Platform supervision module communicates with the secondary P2P module built-in supervision unit via the single-mode optical fiber connecting master and secondary P2P modules.

▪ TTRUPTPSx-S Front Panel Description

The TTRUPTPSx-S includes the four-way splitter/combiner to manage up to four optical modules.

Led ALM: module alarm status	
Off	no active alarms
Blinking Orange	maximum severity level of active alarms: warning
Orange	maximum severity level of active alarms: minor
Blinking Red	maximum severity level of active alarms: major
Red	maximum severity level of active alarms: critical


Led ON: module operating status	
Off	module switched off
Green	power supply is present

DL UL	
SC-APC port: Downlink/uplink optical port (laser aperture) from/to the master Point to Point module	

DL (LED): Optical receiver operating status	
Green	No active alarms
Orange	Received optical power slightly below the operating range (<i>Rx Optical Warn</i> alarm)
Red	Received optical power is below (<i>Rx Optical Low</i> alarm) or above (<i>Rx Optical High</i> alarm) the operating range

UL (LED): Optical transmitter operating status	
Blinking Green	The module is reaching its operating temperature
Green	Optical output power is available
Orange	Optical output power is degraded (<i>Laser Warn</i> alarm)
Off	No optical output power (<i>Laser Fault</i> alarm)

▪ TTRUPTPSx-S block diagram



2 - Components

▪ TTRUPTPSx-S-1 Front Panel Description

TTRUPTPSx-S-1 models do not include the four-way splitter/combiner.

Led ON: module operating status

Off	module switched off
Green	power supply is present

RS232

Factory use only

DL UL

SC-APC port: Downlink/uplink optical port (laser aperture) from/to the master Point to Point module

DL (LED): Optical receiver operating status

Green	No active alarms
Orange	Received optical power slightly below the operating range (<i>Rx Optical Warn</i> alarm)
Red	Received optical power is below (<i>Rx Optical Low</i> alarm) or above (<i>Rx Optical High</i> alarm) the operating range

Led ALM: module alarm status

Off	no active alarms
Blinking Orange	maximum severity level of active alarms: warning
Orange	maximum severity level of active alarms: minor
Blinking Red	maximum severity level of active alarms: major
Red	maximum severity level of active alarms: critical

DL

Downlink RF output port (SMA-f connector type)

UL

Uplink RF input port (SMA-f connector type)

UL (LED): Optical transmitter operating status

Blinking Green	The module is reaching its operating temperature
Green	Optical output power is available
Orange	Optical output power is degraded (<i>Laser Warn</i> alarm)
Red	No optical output power (<i>Laser Fault</i> alarm)

▪ Procedures

"Positioning and Installing Master Unit Plug-in Modules" on page 64

"Optical Connections" on page 70

2.5 - Coverage Extension and Capacity Distribution

The DAS platform components for coverage extension and capacity distribution are the following:

- Service Front End, Single-band/multi-operator interface towards a Service Antenna equipped in the master unit. See "TSFE" below.
- Remote units, multi-carrier equipment connected to the master unit optical components and distributed throughout the territory to be served. For detailed descriptions of remote units refer to the following guides:
 - JMA DAS Platform *Remote Units Installation Guide*.
 - JMA DAS Platform *Next Generation Remote Units Installation Guide*.

2.5.1 - TSFE


Service Front End

JMA Service Front End is a single-band/multi-operator equipment, driven by Digital Donor Front End modules and connected to the Service Antenna/leaky cable to provide wireless signal to the area to be covered.

A single-band single-operator modular off-air repeater can be set-up combining a Digital Donor Front End and a Service Front End. Up to four Donor Front End modules can be connected to a single Service Front End to provide a single-band four-operator repeater.

The Service Front End can also be used in optical systems to provide coverage to the area adjoining the master unit site.

▪ **TSFE block diagram**




The TSFE hosts the duplexer, to be connected to the Service Antenna to separate/combine downlink and uplink paths. In downlink the signals from the Donor Front-End Modules are combined and amplified by a Power Amplifier. In uplink, the RF signal from the Service antenna is amplified by a Low Noise Amplifier (LNA) and split to feed up to four Donor Front-End modules.

Auxiliary ports are available to drive an optical DAS.

2 - Components

▪ TSFE Front Panel Description

The following figure describes the ports and LED on the TSFE.



▪ Procedures

"Installing Master Unit Rack-mount Components" on page 62

"RF Connections" on page 67

"Internal DC Power Supply Connections" on page 77

2.6 - Control and Management

2.6.1 - TSPV

Supervision Module

A single supervision module allows the control and management of an entire JMA DAS including the active sub-rack, where the supervision resides, other 13 sub-racks, and all connected remote units.

NOTE: Two models of supervision are available: TSPV-E and TSPV-N. **TSPV-N modules are required to manage systems that include next generation remote units.**


The supervision communication interfaces allow the DAS to be managed either via a Local Maintenance Terminal (LMT), connected locally to the supervision LAN port, or via a Network Element Manager (NEM). The connection to the NEM can be either a physical (Ethernet WAN) or a modem connection (optional).

The following options are available:

- Wireless modem – Supervision modules with the optional built-in wireless modem allow the remote management of the DAS.
- Energy backup – Supervision modules with the optional integrated energy backup provide four-minute autonomy, in the event of a power outage.

▪ Front Panel Description

The following figure describes the connectors and LEDs on the supervision module.



When all the twelve front ports are connected to monitored devices, an additional power supply unit (SUB-PSUN-MU or SUB-PSUN-MU/48) can be monitored through the RS485 (RJ45) rear port of the sub-rack that hosts the supervision. See "[RS485 Connections](#)" on page 68.

2 - Components

▪ **Procedures**

"Positioning and Installing Master Unit Plug-in Modules" on page 64

"RS485 Connections" on page 68

"External Alarms Connection " on page 86

2.6.2 - TEA-I16


External Alarm Module

The TEAI16 alarm module can be used to increase the number of supported external alarms. Sixteen external alarm inputs are available on the TEA-I16 front panel.

The sixteen input lines are opto-isolated and are activated by a short circuit between input pins (max current flow during short = 6mA; max Vdc at input pins = 3,3V).

Front Panel Description

The following figure describes the ports and LEDs on the TEAI16 alarm module.



Procedures

"Positioning and Installing Master Unit Plug-in Modules" on page 64

"External Alarms Connection " on page 86

2.7 - Power Supply

Two options are available to power up the DAS Platform rack-mount components:

- **TPSU/AC and TPSU/48** – AC or DC power supply plug-in modules to be installed inside SUB-TRX-PSU5N sub-racks. See "[TPSU/AC and TPSU/48](#)" below.
- **SUB-PSUN-MU and SUB-PSUN-MU/48** – Space efficient AC-to-DC and DC-to-DC power supply units, providing up to 2.4kW (AC/DC) / 2.85kW (DC/DC) maximum output power in just one height unit space. See "[SUB-PSUN-MU and SUB-PSUN-MU/48](#)" on page 49.

The most suitable solution can be selected, according to the system total power consumption and to the installation requirements.

A power supply distribution system is available for the remote powering of JMA 48Vdc remote units with up-to-2W output power. See "[Remote Power Supply Distributor](#)" on page 52.

2.7.1 - TPSU/AC and TPSU/48

TPSU/AC and TPSU/48 are JMA AC-to-DC and DC-to-DC plug-in power supply modules that provide up to 100W output power to the DAS Platform active components.


TPSU modules can be connected in parallel to obtain the power required by the system; the following output power is delivered by each module:

- 100W, up to two modules in parallel.
- 90W, three to four modules in parallel.
- 80W, more than four modules in parallel.

Hot-plug 1+1 redundancy feature is supported to achieve high system reliability.


The following figures describe the ports and LEDs on the TPSU modules.

▪ TPSU/AC – Front Panel Description



2 - Components


TPSU/48 – Front Panel Description



TPSU/48 – Protection fuse position and electrical rating

The following figure shows the TPSU/48 protection fuse position and electrical rating.

If the fuse blows, it must be replaced.



TPSU/48: Protection fuse position and electrical rating

Procedures

"Positioning and Installing Master Unit Plug-in Modules" on page 64

"RS485 Connections" on page 68

"Internal DC Power Supply Connections" on page 77

"Connecting External AC Power" on page 78

"Connecting External DC Power" on page 81

2.7.2 - SUB-PSUN-MU and SUB-PSUN-MU/48

SUB-PSUN-MU and SUB-PSUN-MU/48 are JMA space efficient AC-to-DC and DC-to-DC power supply units. For large systems, the SUB-PSU units allow a reduction in the amount of space required for the DAS installation, providing up to 2.4kW (SUB-PSUN-MU) / 2.85kW (SUB-PSUN-MU/48) maximum output power in just one height unit space.

Hot-plug 1+1 redundancy feature is supported: load-sharing power supply modules can be installed to achieve high system reliability. Hot-plugging allows a faulty power supply module to be replaced without powering off the system.


The power supply sub-racks allow the reset of the whole master unit, or of the P2P secondary sub-rack, via the DAS Platform management software (OMT webpages / OMC proprietary software).

▪ SUB-PSUN-MU – Front Panel Description

The following figure describes the ports and LEDs on the SUB-PSUN-MU.

The SUB-PSUN-MU, AC-to-DC power supply unit, can be equipped with up to three AC/DC power supply modules, TPSU/AC-30-1K, to provide up to 2.4kW output power.

NOTE: AC/DC power supply modules (TPSU/AC-30-1K) can be equipped in the SUB-PSUN-MU sub-rack only.




2 - Components

▪ SUB-PSUN-MU/48 – Front Panel Description

The following figure describes the ports and LEDs on the SUB-PSUN-MU/48.


The SUB-PSUN-MU/48, DC-to-DC power supply unit, can be equipped with up to three DC/DC power supply modules, TPSU/48-30-1K, to provide up to 2.85kW output power.

NOTE: DC/DC power supply modules (TPSU/48-30-1K) can be equipped in the SUB-PSUN-MU/48 sub-rack only.



▪ SUB-PSUN-MU/48 – Protection fuses


Each DC input is protected by fuses




TPSU/48-30-1K input protection fuses position and electrical rating

2 - Components

▪ SUB-PSUN-MU and SUB-PSUN-MU/48 – Rear Panel Description



NOTE: To disconnect a power cable, first press the connector release tab, then pull the cable out. Each Vdc output connector is protected by a fuse. If a fuse blows, the green led next to the connector switches off and the O&M software reports an output voltage alarm for the connector. A blown fuse must be replaced.



Detail: 28Vdc output protection fuse and operating status led

▪ Procedures

"Installing Master Unit Rack-mount Components" on page 62

"Internal DC Power Supply Connections" on page 77

"Connecting External AC Power" on page 78

"Connecting External DC Power" on page 81

"Replacement Instructions" on page 90


2.7.3 - Remote Power Supply Distributor

A power supply distribution system is available for the remote powering of JMA 48Vdc remote units with up-to-2W output power.

The power supply distribution system is composed of a Power Supply Unit (PSU) and a Power Distribution Unit (PDU), housed in a 2U - 19" subrack.

The power supply unit can host up to four current-sharing power supply modules (either AC/DC or DC/DC). The configuration allows hot-swapping and supports N+1 redundancy configurations. The voltage from the power supply modules is made available to the 32 DC output ports on the PDU front panel.

A Class 2 DC Distribution Unit version is available to meet the requirements of the US National Electrical Code (NEC). Class 2 distribution systems allow power supply cables to be installed throughout the building without the need of a conduit.



Component	Commercial code	Description
Power supply modules (up to four)	TRPSU/AC-58-1.2k	AC/DC power supply module
	TRPSU/48-58-2k	DC/DC power supply module
Power Distribution Unit (PDU)	SUB-RPSU2-MU/AC	Class 2 DC Distribution Unit and Subrack
	SUB-RPSU2-MU/48	Class 2 DC Distribution Unit and Subrack
	SUB-RPSU-MU/AC	Standard DC Distribution Unit and Subrack
	SUB-RPSU-MU/48	Standard DC Distribution Unit and Subrack

Power supply distribution system components

2.7.3.1 - Power Supply Unit (PSU)

The power supply unit can host up to four current-sharing power supply modules, either AC/DC or DC/DC.

Four LED indicators are available on the front panel of each power supply module.



Example: PSU with TRPSU/AC-58-1.2k, AC/DC power supply modules

▪ Front LEDs description

TRPSU/AC-58-1.2k, AC/DC power supply module - LEDs description

Symbol	Description
~	ON: input ok Blinking: input out of limits
≡	ON: output ok Blinking: overload OFF: no DC output
✖	ON: over-temperature warning Blinking: service
!	ON: fault

TRPSU/48-58-2k, DC/DC power supply module - LEDs description


Symbol	Description
⊖	ON: input ok Blinking: input out of limits
⊕	ON: output ok Blinking: overload
✖	ON: over-temperature warning Blinking: service
!	ON: fault

2 - Components

▪ Rear Panel Description


SUB-RPSU2-MU/AC and SUB-RPSU-MU/AC

Power supply distribution system equipped with AC/DC power supply modules.



SUB-RPSU2-MU/48 and SUB-RPSU-MU/48


Power supply distribution system equipped with DC/DC power supply modules



2 - Components

2.7.3.2 - Power Distribution Unit (PDU)


The following figure describes the ports and LEDs on the Power Distribution Unit (PDU).



32 LED indicators on the front panel of the PDU show the status of each output port, as described in the following table:

Led status	Description
OFF	Switched off port
ON	Green: Regular operation
	Orange: The port is not operating properly. Current absorption out of range
	Red: No output voltage. Port hardware overload protection or broken fuse.

NOTE: Each DC output port is protected by a fuse:



Power Supply distribution system output port protection fuses - position and electrical rating

▪ Procedures

"Installing Master Unit Rack-mount Components" on page 62

"Internal DC Power Supply Connections" on page 77

"Connecting External AC Power" on page 78

"Connecting External DC Power" on page 81

"Connecting DC Power to the Remote Power Supply Distribution System" on page 85


"Replacement Instructions" on page 90

2.8 - Sub-racks for the Installation of Plug-in Components

The following 19" - 3U sub-racks are available to host the master unit 3U plug-in components.

▪ SUB-TRX-PSU5N

The SUB-TRX-PSU5N is a 19" - 3U sub-rack (depth: 270mm, 10.63in) provided with a backplane that allows the management and power supply of active modules. Twelve slots are available to install plug-in components. The slots are numbered from 1 to 12, left to right.



The following connectors are available on the rear of the sub-rack:

- ▶ Five 28Vdc input/output ports, each protected from current overload by a fuse.
NOTE: To disconnect a power cable, first press the connector release tab, then pull the cable out.
- ▶ The RJ45 port (RS485) for connection to the supervision module.
NOTE: Do not insert any module in the slot 12 of the SUB-TRX-PSU5N sub-rack with the rear RS485 port connected to a SUB-PSUN-MU or SUB-PSUN-MU/48. See "[RS485 Connections](#)" on page 68.

2 - Components

▪ SUB-TRX-PSU-D

19" - 3U, 360mm (14.17in) deep subracks are required to host full features Digital Donor Front End modules (TDFE-EGSM-F).

NOTE: Extender boards are required to plug standard–depth modules into deep sub-racks.



Extender Board (TME-SUB-TRX-D)

▪ SUB-HPOI

Modules that do not require power nor management to function can be housed in SUB-HPOI sub-racks, thus allowing a reduction in the cost of the whole system.

▪ Procedures

"Installing Master Unit Rack-mount Components" on page 62

"Positioning and Installing Master Unit Plug-in Modules" on page 64

"RS485 Connections" on page 68


"Internal DC Power Supply Connections" on page 77

2.9 - Forced-air Cooling Unit


JMA forced-air cooling unit TFAN-19-1U-4F-28V ensures the air flow required for proper operation of rack installed equipment. The unit is able to provide a maximum air flow of 180cfm (5m³/min).

▪ Front and Rear Panel Description

The following figure describes the ports and LEDs on the TFAN-19-1U-4F-28V.



TFAN-19-1U-4F-28V: Front view



TFAN-19-1U-4F-28V: Rear view

▪ Procedures

"Installing Master Unit Rack-mount Components" on page 62

"RS485 Connections" on page 68

"Internal DC Power Supply Connections" on page 77

3 - Procedures

The following sections provide instructions for the physical installation, connection, preventive maintenance, and replacement of the master unit components. Each procedure provides instructions for a specific task and includes important precautions and warning statements.




It is important that, before starting work on any equipment, you read the "Safety Rules" on page 108 and the general warning statements referenced in each procedure.

- "Installation" on the next page
 - "Precaution and Warning Statements" on the next page
 - "Installation Site Requirements" on the next page
 - "Installing Master Unit Rack-mount Components" on page 62
 - "Positioning and Installing Master Unit Plug-in Modules" on page 64
- "Connections" on page 66
 - "Precaution and Warning Statements" on page 66
 - "RF Connections" on page 67
 - "RS485 Connections" on page 68
 - "Optical Connections" on page 70
 - "Connecting TCPRIOs to the X-RAN Server" on page 74
 - "Internal DC Power Supply Connections" on page 77
 - "Connecting External AC Power" on page 78
 - "Connecting AC Power to the Master Unit Power Supply Components" on page 79
 - "Connecting AC Power to the Remote Power Supply Distribution System" on page 79
 - "Connecting External DC Power" on page 81
 - "Connecting DC Power to the Master Unit Power Supply Components" on page 83
 - "Connecting DC Power to the Remote Power Supply Distribution System" on page 85
 - "External Alarms Connection " on page 86
 - "Power-up" on page 87
- "Preventive Maintenance" on page 88
 - "Optical Fiber" on page 88
 - "Optical Connectors" on page 88
- "Replacement Instructions" on page 90
 - "Replacing Faulty Plug-in Modules" on page 90
 - "Replacing the TDFE Fan Kit" on page 93
 - "Replacing the ED35TD Fan Unit" on page 91
 - "Replacing Faulty TPSU/AC-30-1K and TPSU/48-30-1K" on page 95
 - "Replacing Faulty TRPSU/AC-58-1.2k and TRPSU/48-58-2k" on page 96

3.1 - Installation

The following sections provide instructions for installation of the master unit DAS components.

 It is important that, before starting work on any equipment, you read the "[Safety Rules](#)" on page 108, the "[Precaution and Warning Statements](#)" below, and the specific precautions and warning statements provided in each procedure.

3.1.1 - Installation Site Requirements

- Make sure that the installation site is safe, properly prepared, and air-conditioned to ensure that the equipment always operates in the proper temperature range.

See JMA DAS Platform Master Unit Installation Guide, "[Technical Specifications](#)" "[Technical Specifications](#)" on page 107.

NOTE: Master unit components must be installed indoors or inside outdoor cabinets.

- Ensure that the equipment is not within direct sunlight at any time.
- Verify that the installation site meets the space and electrical requirements for the installation and operation of the equipment.
- Ensure that you have enough room to comfortably unpack the equipment without risking damage prior to installation.
- Provide enough spacing in front of the equipment for installation and maintenance of the equipment and for enough air to circulate.

3.1.2 - Precaution and Warning Statements

Warning

- A correct system installation and setting procedure requires a good knowledge of and experience in installing telecommunication equipment.
- To ensure proper installation and configuration, these activities should be performed by skilled and experienced personnel only.
- Before installing the equipment, carefully read the safety rules attached to this technical handbook. See "[Safety Rules](#)" on page 108.
- Before starting work on any equipment, make sure it is isolated from its power supply source.
- If not approved by JMA, repainting any components of the DAS will void warranty.
- The equipment is intended to be installed in a Restricted Access Location (RAL) where the equipotential bonding has been applied. RAL is defined as a location for equipment where both of the following conditions apply:
 - Access can be gained only by SERVICE PERSONS or by USERS who have been instructed about the reasons for the restrictions applied to the location and about any precautions that shall be taken.
 - Access is through the use of a TOOL or lock and key, or other means of security, and is controlled by the authority responsible for the location.

3 - Procedures

- In Denmark, Finland, Norway and Sweden, the equipment intended for connection to other equipment or a network shall have a marking stating that the equipment must be connected to an earthed mains socket-outlet.

In Finland: "*Laitte on liitettävä suojakoskettimilla varustettuun pistorasiaan*".

In Norway: "*Apparatet må tilkoples jordet stikkontakt*".

In Sweden: "*Apparaten skall anslutas till jordat uttag*".

In Denmark: "*Apparatets stikprop skal tilsluttes en stikkontakt med jord, som giver forbindelse til stikproppens jord*".

- Modular equipment, intended to be housed inside a rack cabinet, must be installed within a protected access area only.

This area must be opportunely protected by security system that will exclude the entry, even if accidental, to unauthorized and untrained personnel. Alternatively, the cabinet, in which the equipment is housed, must be closed on all sides, to allow the access to internal parts to authorized personnel only.

- The equipment is intended to be installed also in an IT power distribution system.

Caution: A cabinet cooling forced air ventilation system, able to provide an air flow of up to 180cfm (5m³/min), is required to ensure cabinet installed equipment proper operation.

3.1.3 - Installing Master Unit Rack-mount Components

Following are the requirements and best practices for the correct installation of the master unit rack-mount components inside rack cabinets.

Warning

- The modular master unit must be positioned indoor or inside outdoor cabinets to guarantee the protection of the equipment against atmospheric agents, humidity and temperature changes. See "Technical Specifications" on page 107.
- Before installation, make sure that all the components of the system are isolated from the main power supply.
- Also make sure that the switches of all the power supply units equipped in the DAS are set to O (OFF).
- It is recommended to provide the system with a UPS (Uninterruptible Power Supply) unit to ensure the operation of equipment, should the mains supply fail.

3.1.3.1 - Positioning Rack-mount Components


- At least one rack unit distance is required between active sub-racks for air flow to assure proper cooling.
- The forced-air cooling units (TFAN-19-1U-4F-28V) should be strategically positioned to ensure higher air flow volume, where required (e.g. adjacent to sub-racks hosting power supply modules, optical modules, or TCPRIPOIs).
- Whenever a TCPRIPOI is installed inside a sub-rack, it is mandatory to install an adjacent forced-air cooling unit (TFAN-19-1U-4F-28V) above or below the sub-rack and to leave at least one rack unit's space on the opposite part, to ensure proper air-flow volume.

Each sub-rack hosting TCPRIPOI units requires:

- one rack unit's space above (or below)

and

- a forced-air cooling sub-rack (TFAN) on the opposite part



NOTE: When deploying a TCPRIPOI inside an existing DAS, always check the RF link budget; make sure the RF link budget remains unchanged if longer cables are required.

- To make connections easier, position the sub-racks as follows:
 - Install the Service Front End over the sub-rack(s) hosting RF interface modules (with TDFE sub-racks over POI sub-racks).
 - Install the sub-racks hosting RF interface modules and/ or passive components over optical sub-racks or sub-racks hosting optical modules.
 - Install the sub-racks hosting power supply modules in the lowest position.

3.1.3.2 - Installing Rack-mount Components


NOTE: Before installation read the "Safety Rules" on page 108 and the "Precaution and Warning Statements" on page 60.


To install rack-mount components, perform the following actions:

1. Before installing sub-racks inside the rack cabinet, fasten the rack cabinet to the site floor, to prevent it from turning over.
2. Connect the rack cabinet to the station ground.
3. Mount the horizontal rails for support of the equipment.
4. Insert each sub-rack into the rails and slide it into position carefully. Insert sub-racks starting from the bottom.

NOTE: At least one rack unit distance is required between active sub-racks for air flow to ensure proper cooling. See " Positioning Rack-mount Components" on the previous page.

5. Fix each sub-rack to the vertical mounting guides of the rack cabinet using four M6x16 cylindrical cross-head screws, to be inserted into the proper slots.
6. Connect each sub-rack to the rack cabinet ground bus bar.

Connectors with ground protection are located on the back panel of active sub-racks and can be identified by the ground symbol, . See the following close-up detail of a correct ground connection.



NOTE:

- A washer (preferably a star washer) must be used for anti-rotation.
- Only copper cables shall be used for grounding purposes.

3.1.4 - Positioning and Installing Master Unit Plug-in Modules

3.1.4.1 - Positioning Plug-in Modules

Following are the instructions for the correct positioning of the DAS plug-in modules inside their sub-racks:

- Do not insert any module in the slot 12 of a SUB-TRX-PSU5N with the rear RS485 port to be connected to a SUB-PSUN-MU or SUB-PSUN-MU/48. See ["RS485 Connections" on page 68](#).
- TRPSU/AC-58-1.2k and TRPSU/48-58-2k power supply modules to be equipped inside the power supply distribution system (SUB-RPSUx) should be installed left-to-right.
- To make connections easier, install and connect one TDTPOI at a time. Also, install adjacent TDTPOIs right-to-left or left-to-right.
- Point-to-Point link: When the remote sub-rack is equipped with two or three secondary P2P modules, insert only one secondary module in slots 1 to 6. The module installed in this position communicates with the DAS supervision module. Install the other PTP secondary modules in slots 7 to 12.
- The SUB-TRX-PSU-D, 19" - 3U, 360mm (14.17in) deep sub-rack, is required to host full features Digital Donor Front End modules (TDFE-EGSM-F). Extender boards are required to plug standard-depth modules into deep sub-racks. See ["Sub-racks for the Installation of Plug-in Components" on page 56](#).
- Always make sure that the DAS is equipped with the same type of power supply modules (same commercial code on handles).

3.1.4.2 - Installing Plug-in Modules inside sub-racks

NOTE: Before installation read the ["Safety Rules" on page 108](#) and the ["Precaution and Warning Statements" on page 60](#).

- **All plug-in modules, except TDTPOIs**

To install plug-in modules, insert each module into the sub-rack until it is fully seated in the slot, then tighten the screws on the module front panel, to fasten the module to the sub-rack.

In active sub-racks guide rails are clipped in. If necessary, pull to remove them.

- **Supervision with built-in optional wireless modem**


When the DAS supervision module is equipped with the built-in optional wireless modem, prior to installing the module inside the sub-rack, insert the SIM card, as described in the following procedure.

- **SIM card installation**

The SIM card must be enabled for data transfer and preferably unlocked (PIN code disabled).

To insert the SIM card, perform the following actions:


1. Place the supervision module on a stable surface.
2. Locate the SIM card slot. The following figure shows the position of the SIM card holder.



3. Insert the SIM card into the SIM slot, with the gold contacts facing down and the clipped corner going in first.
4. Gently push the SIM card into the slot, until it clicks into place.

▪ TDTPPOIs

To make connections easier, install and connect one TDTPPOI at a time. Also, install adjacent TDTPPOIs right-to-left or left-to-right.



To install each TDTPPOI, perform the following actions:

1. Insert the module into the slot, but do not insert the module completely to leave enough space for coaxial cable(s) from/to the Base Station to be routed to the TDTPPOI 7/16 RF port(s). See figure above.
2. Provide coaxial cable(s) to be connected to the TDTPPOI with a 7/16 90° male connector, then route the cables from the rear of the sub-rack, through the space over the sub-rack.
3. Connect the coaxial cable(s) to the 7/16 port(s), but do not tighten the connection yet.
4. Push the module completely into the sub-rack and tighten the captive screws available on the module front panel to fasten the module to the sub-rack.
5. Tighten the 7/16 90° male connector(s) to the TDTPPOI 7/16 (f) port(s) using a 7/16-inch torque wrench.

3.2 - Connections

The following sections provide instructions to perform RF, RS485, optical, external alarms, and power supply connections. Instructions to connect the TCPRIPOI to the XTRAN Server (CPRI) are also provided.



It is important that, before starting work on any equipment, you read the "Safety Rules" on page 108, the following warnings, and the specific precautions and warning statements provided in each procedure.

3.2.1 - Precaution and Warning Statements

- Ethernet or coaxial ports that use a shielded cable must be shielded and grounded at both ends.
- Bare conductors must be coated with antioxidant before crimp connections are made.
- Verify that the intra-building port(s) of the equipment or subassembly are suitable for connection to intra-building or unexposed wiring or cabling only. The intra-building port(s) of the equipment or subassembly **must not** have metallic connections to interfaces that connect to the OSP or its wiring. These interfaces are designed for use as intra-building interfaces only (Type 2 or Type 4 ports as described in GR-1089-CORE, Issue 6) and require isolation from the exposed OSP cabling. The addition of primary protectors is insufficient protection for metallic connections between these interfaces and OSP wiring.

3.2.2 - RF Connections


Caution: in any event, the installer should never connect an antenna to the master unit *BTS* port.

Connections among the DAS master unit components

RF connections among the DAS master unit components change according to the application scenario: please refer to the connection scheme provided with the supply.

NOTE: The color of the heat shrink tubing applied to RF and sync cables allows easy identification of the master unit RF connections:

- Black heat shrink tubing identifies DL (Downlink) and sync (synchronization) cables.
- White heat shrink tubing identifies UL (Uplink) cables.



Connections to the antenna system

Service Front End

Connect the *SERVICE ANT* port on the front of the Service Front End to the service antenna. See "[TSFE Front Panel Description](#)" on page 43


3.2.3 - RS485 Connections

The DAS supervision module is able to manage the sub-rack it is equipped in, up to other 12 active sub-racks, and an additional power supply unit (SUB-PSUN-MU or SUB-PSUN-MU/48).

The supervision module provides automated identity of the monitored deployed system elements. Each monitored sub-rack is assigned an address. Plug-in components inside a sub-rack are identified by their slot number.

- **Monitored sub-racks installed at the master unit site**

- Connect the supervision RS485 ports, labeled 1 to 8, to the RS485 ports (RJ45) on the rear panel of the sub-racks to be monitored.



- If ports S1 to S4 are not connected to remote P2P sub-racks, they can be used to manage additional sub-racks installed at the master unit site.
Connect the supervision RS485 ports, labeled S1 to S4, to the RS485 ports (RJ45) on the rear panel of the sub-racks to be monitored.

- An additional RS485 port is available on the rear panel of the active sub-rack hosting the supervision module.
This port is used only when the DAS is equipped with the power supply unit (SUB-PSUN-MU or SUB-PSUN-MU/48) in addition to other 12 monitored sub-racks, connected to the 12 RS485 front ports.

NOTE: The power supply unit, connected to the rear RS485 port, is assigned slot position 12. Therefore do not insert any module in the slot 12 of the sub-rack with the rear RS485 port connected to a SUB-PSUN-MU or SUB-PSUN-MU/48.

When TPSU plug-in power supply modules are equipped in monitored sub-racks, an RS485 port is also available on the PSU front panel. It makes no difference which RS485 port is connected to the

3 - Procedures

supervision, either the one on the rear panel of the sub-rack or the one on the front panel of the PSU. When the hot-plug 1+1 redundancy feature is implemented it makes no difference which power supply module is connected to the supervision module.

▪ Point to Point links

- Connect the master P2P modules to ports labeled S1 to S4 to manage remote sub-racks equipped with secondary P2P modules. The remote sub-racks connected via optical link to ports S1 to S4 take addresses 9 to 12.

The DAS Platform supervision unit communicates with the secondary P2P module built-in supervision unit via the single-mode optical fiber connecting master and secondary P2P modules.

NOTE: When remote optical sub-racks are equipped with two or three secondary P2P modules, the DAS Platform supervision communicates with the module installed on the left side of the remote sub-rack (slots 1 to 6). The other PTP secondary modules must be installed in slots 7 to 12.

- Connect the remote SUB-PSUN-MU or SUB-PSUN-MU/48 to the RS485 port available on the rear panel of the remote sub-rack, hosting P2P secondary modules.

NOTE: The power supply unit, connected to the rear RS485 port of a remote sub-rack, is assigned slot position 12. Therefore, do not insert any module in the slot 12 of a remote sub-rack with the rear RS485 port connected to a SUB-PSUN-MU or SUB-PSUN-MU/48.

3.2.4 - Optical Connections

It is important that, when dealing with optical fibers and connectors, you read the "Safety Rules" on [page 108](#) and observe the following precautions and warning statements.

Caution: Fiber optic devices are sensitive to static electricity.



When handling fiber optic devices, observe the following precautions:

- Never stare directly into fiber optic connectors and fibers. Invisible emitted laser beams can damage your eyes.
- Always cover optical connectors, adapters, and optical ports with caps to prevent dust from accumulating on the interface. Remove fiber optic protective caps prior to making connections.
- Optical connections must be made with care to avoid damaging the optical fiber or connectors.
- Do not bend fiber optic cable with a tight radius of curvature: the cable might be damaged and losses within the fiber might occur.
- Before mating fiber optic connectors, inspect and clean the connectors and optical ports to ensure optimized performance. Dirty connector interfaces can cause degradation of optical signal. Inspection can be carried out via a fiber optic microscope (optical fiber scope) to detect scratches, dirt, dust, and other contaminants on optical connector end faces.



Before inspection, always turn off the laser source. Never inspect a fiber while looking into it or connecting it to a fiber scope while the laser is on.

See "[Optical Connectors](#)" on [page 88](#) for inspection and cleaning procedures.

3.2.4.1 - Connecting P2P modules

Master and secondary P2P modules are connected via single mode optical fiber (SMR 9/125), with uplink and downlink optical signals transmitted over the same optical fiber (WDM).

The following procedure is recommended to perform optical connections:

1. Check optical fiber type is SMR 9/125.
2. Remove protective caps from each optical connector receptacle just before making optical connections.
 - ⚠ Never stare directly into fiber optic connectors and fibers.
3. Inspect and clean jumpers and adaptors that have been left exposed without dust caps. See "[Optical Connectors](#)" on [page 88](#) for inspection and cleaning procedures. ⚠ Never stare directly into fiber optic connectors and fibers.
4. Connect master and secondary P2P modules *DL/UL* optical ports.

3.2.4.2 - Connecting Master Unit Plug-in Optical Modules to Remote Units

Master unit TTR modules and remote units are connected via single mode optical fiber (SMR 9/125), with uplink and downlink optical signals transmitted over the same optical fiber (WDM).

The following procedure is recommended to perform optical connections:

To correctly install optical transceivers:

1. Check optical fiber type is SMR 9/125.

3 - Procedures

2. Remove protective caps from each optical connector receptacle just before making optical connections.

⚠ Never stare directly into fiber optic connectors and fibers.


NOTE: Remove the transition and the conduit fitting, if mounted on the remote unit optical connector.

3. Inspect and clean jumpers and adaptors that have been left exposed without dust caps. See "[Optical Connectors](#)" on page 88 for inspection and cleaning procedures. ⚠ Never stare directly into fiber optic connectors and fibers.

4. Connect remote units to optical modules.

- **TTRU1W-S-M, TTRU2W-S-M, TTRU4W-S-M**


Connect *DL/UL* SC-APC ports, on the module front panel, to the optical ports on remote units.



- **TTRX24W-S-M**

The TTRX24W-S-M provides the optical interface towards up to two MIMO remote units.

The optical ports of each MIMO remote unit must be connected to a different transmitter (A, B).




- **TTRU2W-S-M-C2**

The TTRU2W-S-M-C2 optical module supports up to two locations, with one fiber strand per remote location/per MIMO path.

Connect the *DL/UL 1* optical port to the optical splitter in remote location 1.

3 - Procedures

Connect the *DL/UL 2* optical port to the optical splitter in remote location 2.



5. Properly seal the remote unit optical connection.

When connecting optical fibers to remote units, a waterproof junction is critical to ensure the IP66 rating provided by the equipment enclosure or by the optional IP66 protection kit.

See *JMA DAS Platform Remote Units Installation Guide* for details.


3.2.4.3 - Connecting the ED35TD to Next Generation Remote Units

Next generation remote units are connected to the master unit transceiver ED35TD via single mode optical fiber, with MIMO1 and MIMO2 uplink and downlink optical signals transmitted over the same optical fiber.

NOTE: Transceivers to be installed into the optical ports of the ED35TD are delivered with the remote unit to be connected to the ED35TD. Optical transceivers installed into the ED35TD optical ports must have the same color (black) on the latch.

Connect the optical cable from the remote unit to the optical port on the ED35TD as described in the following steps:

1. Make sure to install transceivers with the same color same color on the latch (same TX/RX wavelength) into the ED35TD optical ports.
2. Label optical cables consistently to identify the remote unit connected to each port on the ED35TD.
3. Insert one SFP optical transceiver into each optical port of the ED35TD to be connected to remote units.



Insert optical transceivers as follows:

- ▶ Remove each SFP optical transceiver from its box shortly before making installation.
 - ▶ Correctly align the SFP optical transceiver with the optical port.
 - ▶ Gently press the SFP+ optical transceiver into the port until it snaps into place.
 - ▶ Remove the protective cap from each transceiver optical connector receptacle. Remove protective caps shortly before making connections.
4. Connect the optical cable(s) from the remote unit to the optical transceiver(s).

3.2.5 - Connecting TCPRIPOIs to the XLAN Server

The physical CPRI interface of the server is provided by the PCIe CPRI card. The TCPRIPOI must be connected to the PCIe CPRI card for digital baseband data-flow transfer.

NOTE

1. Label CPRI cables consistently to allow easy identification of the TCPRIPOIs connected to specific PCIe ports.
2. When dealing with optical fibers and connectors:

Caution: Fiber optic devices are sensitive to static electricity.



When handling fiber optic devices, observe the following precautions:

- Never stare directly into fiber optic connectors and fibers. Invisible emitted laser beams can damage your eyes.
- Always cover optical connectors, adapters, and optical ports with caps to prevent dust from accumulating on the interface. Remove fiber optic protective caps prior to making connections.
- Optical connections must be made with care to avoid damaging the optical fiber or connectors.
- Do not bend fiber optic cable with a tight radius of curvature: the cable might be damaged and losses within the fiber might occur.
- Before mating fiber optic connectors, inspect and clean the connectors and optical ports to ensure optimized performance. Dirty connector interfaces can cause degradation of optical signal. Inspection can be carried out via a fiber optic microscope (optical fiber scope) to detect scratches, dirt, dust, and other contaminants on optical connector end faces.



Before inspection, always turn off the laser source. Never inspect a fiber while looking into it or connecting it to a fiber scope while the laser is on.

To connect optical cables, perform the following actions:

▪ Step 1

Insert an SFP+ optical transceiver into each port of the TCPRIPOI to be connected to the server or to a daisy-chained TCPRIPOI.

Install SFP+ optical transceivers as follows:

- Remove each SFP+ optical transceiver from its box shortly before making installation.
- Correctly align the SFP+ optical transceiver with the port.
- Gently press the SFP+ optical transceiver into the port until it snaps into place.


▪ Step 2

NOTE: Before making CPRI connections, remove the protective cap from the transceiver optical connector receptacle.

▸ Single point-to-point topology

In configuring the XLAN server, connect the cable from/to the XLAN Adaptive Baseband Server (ABS) to the SFP1 port on the TCPRIPOI front panel.

3 - Procedures




Single TCPRIO connections

▸ **Chain topology**

In configuring the XRAN server, connect:

- the cable from/to the XRAN ABS to the SFP1 port on the master TCPRIPOI front panel
- the SFP2 and SFP3 ports on the master TCPRIPOI to the SFP1 port on the daisy-chained TCPRIPOI units
- the SFP2 and SFP3 ports on each daisy-chained TCPRIPOI to the SFP1 port on lower-level daisy-chained TCPRIPOI units

Up to two daisy-chained TCPRIPOI units are supported for each TCPRIPOI.



TCPRIPOI chain topology connections

3.2.6 - Internal DC Power Supply Connections

This section describes how to connect the DAS rack-mount components to the DAS components providing power supply.

NOTE: The ED35TD can be connected either to the DAS sub-racks providing power supply or to an external DC power source. To connect the ED35TD to an external DC power source refer to "[Connecting External DC Power](#)" on page 81.




Warning

- It is important that, before starting work on any equipment, you read the "[Safety Rules](#)" on page 108.
- Before starting work on any equipment, it shall be isolated from its power supply source.

Connect DAS rack-mount components to the DAS components providing power supply as follows:

1. Ground active sub-racks.

Connectors with ground protection are located on the back panel of the active sub-racks and can be identified by the ground symbol . See [page 63](#) for details.

2. Connect sub-racks to be powered to sub-racks hosting power supply components. Use the 28Vdc outputs/inputs, available on the rear panel of active sub-racks.

Caution: To disconnect power cables, first press the connector release tab, then pull the cable out.

NOTE: When active sub-racks are equipped with their own plug-in AC or DC power supply modules, no connections are required.

3.2.7 - Connecting External AC Power

This section describes how to connect an external customer provided AC power source to the following DAS components:

- TPSU/AC plug-in modules.
- TPSU/AC-30-1K modules, equipped in SUB-PSUN-MU sub-racks.
- AC-powered Remote Power Supply Distributor equipped with TRPSU/AC-58-1.2k, AC/DC power supply modules.

It is important that, before starting work on any equipment, you read the "[Safety Rules](#)" on page 108 and the following precaution and warning statements.



Warning

- Before starting work on any equipment, make sure it is isolated from its power supply source.
- Make sure that the power supply source provides the nominal voltage prescribed.
- Equipment shall be connected to an earthed socket-outlet. Earthing connection of the socket-outlet requires verification by a skilled person.
- Following are the AC power supply cord requirements:
 - If it is necessary to fit an AC power supply plug to a power cable, the User must observe the standard wire coloring in the country of installation.
The User must also ensure that the protective earth wire would be the last to break if the cable is subject to excessive strain.
 - The detachable AC power supply cord set shall be no lighter than light PVC sheathed flexible cord (H03VV-F) for indoor installation and rubber (H07RN-F) or PVC (SJTW, for the United States and Canada only) for outdoor installation, according to IEC60227, UL 817 for the United States, and CSA C22.2 No.21 for Canada.
 - The detachable AC power supply cord set shall comply with the following requirements:
 - nominal voltage 240Vac
 - maximum operating temperature $\geq 60^{\circ}\text{C}$ (140°F)
 - For US/Canada market:
 - Minimum cord length is 1.5m.
 - Power supply cords must be no longer than 4.5m, if used in ITE Rooms.
 - Flexible power supply cords must be compatible with Article 400 of the NEC and Tables 11 and 12 of the CEC.
 - Power supply cords for outdoor equipment must be suitable outdoor use type as required by Section 400.4 of the NEC and Rule 4-012 of the CEC, that is, marked water resistant, outdoor, W or W-A.
 - Power supply cords must have attachment plugs rated not less than 125 percent of the rated current of the equipment.

3.2.7.1 - Connecting AC Power to the Master Unit Power Supply Components



Caution: It is strongly recommended that a thermal magnetic circuit breaker is installed upstream the system; if an upstream circuit breaker is not available, at power-up you must simultaneously switch on all the power supply modules equipped in the master unit.

▪ TPSU/AC

To connect AC power to the TPSU/AC, perform the following actions:

1. Verify that each active sub-rack in the system is connected to the nearest ground reference location. See "[Internal DC Power Supply Connections](#)" on page 77.
2. Make sure that the AC mains switch of each TPSU/AC, equipped in the system, is set to off (0).
3. Make sure that the power supply source provides the AC voltage prescribed: 100-240Vac nominal (range: 85 to 264Vac).
4. Connect the AC power supply cord plug to the AC *MAINS* socket, available on the front panel of each TPSU/AC.

NOTE: The recommended gauge of the AC power supply cord is AWG 16.

▪ TPSU/AC-30-1K (SUB-PSUN-MU)



Warning: Since the plug on the power supply cord is intended to serve as the disconnect device, the socket-outlet shall be installed near the equipment and shall be easily accessible.

To connect AC power to the TPSU/AC-30-1K, perform the following actions:

1. Verify that the switch upstream the unit is open.
2. Verify that the SUB-PSUN-MU sub-rack and all active sub-racks in the system are connected to the nearest ground reference location. See "[Internal DC Power Supply Connections](#)" on page 77.
3. Make sure that the power supply source provides the AC voltage prescribed: 100-240Vac nominal (range: 85 to 264Vac).
4. Connect the AC power supply cord plug to the AC socket, available on the front panel of each TPSU/AC-30-1K, equipped in the SUB-PSUN-MU power supply unit.

NOTE: The recommended gauge of the AC power supply cord is AWG 14.

3.2.7.2 - Connecting AC Power to the Remote Power Supply Distribution System



Warning: Since the plug on the power supply cord is intended to serve as the disconnect device, the socket-outlet shall be installed near the equipment and shall be easily accessible.

To connect JMA remote power supply distribution system to the AC power supply, perform the following actions:

Step 1. Verify that the switch upstream the unit is open.


Step 2. Verify that the power supply distribution system is connected to the nearest ground reference location. See "[Internal DC Power Supply Connections](#)" on page 77.

3. Make sure that the power supply source provides the AC voltage prescribed (100–120 to 200–277Vac).

3 - Procedures

4. Connect the AC power supply cord(s) to the AC socket(s), available on the rear panel of SUB-RPSU2-MU/AC or SUB-RPSU-MU/AC power distributor.

NOTE: The recommended gauge of the AC power supply cord is AWG 14.



3.2.8 - Connecting External DC Power

This section describes how to connect an external customer provided DC power source to the following DAS components:

- TPSU/48 plug-in modules.
- TPSU/48-30-1K modules, equipped in SUB-PSUN-MU/48 sub-racks.
- DC-powered Remote Power Supply Distributor equipped with TRPSU/48-58-2K, DC/DC power supply modules.
- ED35TD.

NOTE: The ED35TD can be connected either to an external DC power source or to the DAS sub-racks providing power supply. To connect the ED35TD to the DAS sub-racks providing power supply refer to "[Internal DC Power Supply Connections](#)" on page 77.

It is important that, before starting work on any equipment, you read the "[Safety Rules](#)" on page 108 and the following warning statements.



Warning


- Before starting work on any equipment, make sure it is isolated from its power supply source.
- Make sure that the power supply source provides the nominal voltage prescribed.
- When installing the DC power supplied equipment, the positive terminal of the DC mains supply must be connected to protective earth, Common DC Return (DC-C) configuration.
- According to the manufacturer, the Master Unit DC power supply module shall be installed in an isolated secondary circuit, which is separated from primary circuit by Reinforce or Double insulation.
- Following are the DC power supply cord requirements:
 - The color of the wires inside the power cord should be compliant with the standard wire coloring in the country of installation.
 - The detachable DC power supply cord set must meet the requirements for indoor or outdoor use, in accordance with the standards of the country of installation.
 - The detachable DC power supply cord set shall comply with the following requirements:
 - nominal voltage 72Vdc
 - maximum operating temperature $\geq 75^{\circ}\text{C}$ (167°F)
 - For US/Canada market:
 - Minimum cord length is 1.5m, with certain constructions (such as external power supplies) allowed to consider both input and output cord lengths into the requirement.
 - Power supply cords must be no longer than 4.5m, if used in ITE Rooms.
 - Flexible power supply cords must be compatible with Article 400 of the NEC and Tables 11 and 12 of the CEC.
 - Power supply cords for outdoor equipment must be suitable outdoor use type as required by Section 400.4 of the NEC and Rule 4-012 of the CEC, that is, marked water resistant, outdoor, W or W-A.

3 - Procedures

- Power supply cords must have attachment plugs rated not less than 125 percent of the rated current of the equipment.

3.2.8.1 - Connecting DC Power to the Master Unit Power Supply Components


▪ **TPSU/48**

 **Warning:** It is necessary to provide an external protective device from overcurrent (50A, 250V). The protective device should be compliant with the standards of the country of installation.

To connect DC power to the TPSU/48, perform the following actions:

1. Verify that each active sub-rack in the system is connected to the nearest ground reference location. See "[Internal DC Power Supply Connections](#)" on page 77.
2. Make sure that the 48Vdc switch of each TPSU/48 equipped in the system is set to off (0).
3. Make sure that the power supply source provides the DC voltage prescribed: - 48Vdc nominal (range: -72 to -36Vdc).
4. Connect DC power following the instructions provided in the "Easy Quick DC cabling procedure", delivered with the equipment.

Three-pole connector PIN assignment:

	1	0 Vdc
	2	Not Connected
	3	- 48Vdc

NOTE: The recommended gauge of the DC power supply cord is AWG 18.

▪ **TPSU/48-30-1K (SUB-PSUN-MU/48)**

 **Warning**

- The Vdc input connector is the means to disconnect the equipment from d.c. mains supply. Remove it to disconnect the equipment from power supply source before operation.
- It is necessary to provide an external protective device from overcurrent (50A, 250V). The protective device should be compliant with the standards of the country of installation.
- Regarding resistance of earthing conductors, the manufacturer declares that the equipment is tested with 48A of test current for 1 minute, applied between the protective earthing terminal and accessible conductive parts.
- The ACTRONIC AR35.40.135 power supply filter, or an equivalent type, shall be installed between the equipment Vdc input and the DC power source, in order to achieve compliance with the conducted emission limits.
- The FAIR-RITE PRODUCTS CORP. model 0431176451 snap ferrite, or an equivalent type, shall be installed near the equipment Vdc input, in order to achieve compliance with the radiated emission limits.

To connect DC power to the TPSU/48-30-1K, perform the following actions:

1. Verify that the SUB-PSUN-MU/48 sub-rack and all active sub-racks in the system are connected to the nearest ground reference location. See "[Internal DC Power Supply Connections](#)" on page 77.
2. Make sure that the power supply source provides the DC voltage prescribed: - 48Vdc nominal (range: -72 to -36Vdc).

3 - Procedures

3. Follow the instructions provided in the "Easy Quick DC cabling procedure", provided with the equipment, to connect DC power supply to the Vdc input, available on the front panel of each TPSU/48-30-1K, equipped in the SUB-PSUN-MU/48 power supply unit.

NOTE: The recommended gauge of the DC power supply cord is AWG 10.


3.2.8.2 - Connecting DC Power to the ED35TD



Warning: The equipment is intended and designed to be connected to a DC power source with a maximum transient voltage up to 1.5kV.

To connect DC power to the ED35TD, perform the following actions:

- 1. Connect the ED35TD protective earthing terminal to the nearest ground reference location for electrical safety.**

The protective earthing terminal is located on the back panel of the ED35TD sub-rack and can be identified by the ground symbol .

NOTE: The grounding conductor gauge is AWG 14-12, with color compliant with the standard wire coloring in the country of installation.

2. Make sure that the power supply source provides the DC voltage prescribed: -28 to -50Vdc.
3. Connect DC power.

NOTE: The gauge of the DC power supply cord is AWG 14.

3.2.8.3 - Connecting DC Power to the Remote Power Supply Distribution System


Warning

- The Vdc input connector is the means to disconnect the equipment from d.c. mains supply. Remove it to disconnect the equipment from power supply source before operation.
- It is necessary to provide an external protective device from overcurrent (50A, 250V). The protective device should be compliant with the standards of the country of installation.
- Regarding resistance of earthing conductors, the manufacturer declares that the equipment is tested with 48A of test current for 1 minute, applied between the protective earthing terminal and accessible conductive parts.

To connect JMA remote power supply distribution system to the DC power supply, perform the following actions:

1. Verify that the power supply distribution system is connected to the nearest ground reference location. See "[Internal DC Power Supply Connections](#)" on page 77.
2. Make sure that the power supply source provides the DC voltage prescribed (-72 to -40Vdc).
3. Follow the instructions provided in the "Easy Quick DC cabling procedure", provided with the equipment to connect DC power supply to the TRPSU/48-58-2K Vdc input(s), available on the rear panel of the SUB-RPSU2-MU/48 or SUB-RPSU-MU/48 power distributor.

NOTE: The recommended gauge of the DC power supply cord is AWG 10.




3.2.9 - External Alarms Connection

Four external alarm inputs and four dry contact outputs are available on the supervision module front panel. The four input lines are opto-isolated and are activated by a short circuit between input pins (max current flow during short = 6mA; max Vdc at input pins = 3.3V).


Please refer to the following pin-out when connecting external alarm inputs and outputs to the supervision module EXT OUT and EXT IN connectors.

▪ **External alarm connectors pin-out**

- EXT IN pin-out



- EXT OUT pin-out



▪ **External Alarms Wiring**

Four-pole, female connectors to be plugged into the EXT OUT / EXT IN connectors are provided standard with the supervision module.

To connect external alarms, perform the following actions:

1. Plug the female connectors to be wired into the supervision EXT OUT/EXT IN connectors.
2. Use a screwdriver to gently slide the small metal locking tab on the side of each contact.
3. Insert the exposed part of the wire into the contact receptacle.
4. When the wire is in place, release the tab.



Master Unit: 2x4-pole female connector (to be wired, left; wired, right)

3.3 - Power-up

Caution: to prevent damages to the equipment, before power-up, make sure that the RF interface modules (TDTPOI/ TLPPOI/POI/TAPOI or TDFE modules) are NOT connected to the signal source.

- Switch on active sub-racks:
 - If a thermal magnetic circuit breaker is installed upstream the System (recommended), set the switches present on the front panels of the power supply modules equipped in the System to the I (ON) position, then close the upstream circuit breaker.
 - If an upstream circuit breaker is not available, make sure to **simultaneously** switch on all the power supply modules equipped in the system.

3.4 - Configuration and Management

After power-up, configuration and management of the master unit is performed remotely via the OMT application installed on the supervision module.

Refer to the following software guides for details:

- JMA DAS Platform – Remote Monitoring User Guide.
- JMA DAS Platform – Local Commissioning User Guide.

3.5 - Preventive Maintenance

Preventive maintenance consists in scheduling routine maintenance of equipment to ensure optimal working conditions, thus preventing problems that might lead to equipment failure.

Following are the recommended preventive maintenance procedures for the JMA DAS Platform components.



It is important that, before starting work on any equipment, you read the "Safety Rules" on page 108, the general warning statements referenced in each procedure, and the specific warnings provided in each procedure.

3.5.1 - Optical Fiber

It is a good practice to periodically check the integrity of the optical fiber.

3.5.2 - Optical Connectors

Dirty connectors end faces can cause degradation of optical signals. To ensure optimal performance, inspect and clean fiber optic connectors.

Caution: Fiber optic devices are sensitive to static electricity.



When handling fiber optic devices, observe the following precautions:

- Never stare directly into fiber optic connectors and fibers. Invisible emitted laser beams can damage your eyes.
- Always cover optical connectors, adapters, and optical ports with caps to prevent dust from accumulating on the interface. Remove fiber optic protective caps prior to making connections.
- Optical connections must be made with care to avoid damaging the optical fiber or connectors.
- Do not bend fiber optic cable with a tight radius of curvature: the cable might be damaged and losses within the fiber might occur.
- Before mating fiber optic connectors, inspect and clean the connectors and optical ports to ensure optimized performance. Dirty connector interfaces can cause degradation of optical signal. Inspection can be carried out via a fiber optic microscope (optical fiber scope) to detect scratches, dirt, dust, and other contaminants on optical connector end faces.



Before inspection, always turn off the laser source. Never inspect a fiber while looking into it or connecting it to a fiber scope while the laser is on.

- **Cleaning methods**

For fiber optic cleaning, JMA recommends dry cleaning methods that do not use solvent.

The following methods are recommended to clean fiber optic ends and optical connector end faces.

- **Reel cleaner (pigtailed devices)**

- Fiber optic reel cleaner is a reliable dry cleaning method that ensures uniform results. It is a moderately abrasive fiber optic cleaning method.

3 - Procedures

Cleaning procedure:

Before cleaning optical fiber, make sure that the laser source is off.

- Remove the fiber optic protective cap.
- Push and hold the reel cleaner lever to expose the 2 micron fiber cleaning cloth.

Press lightly and rub the connector tip downward.

▸ **Stick cleaners**

Sticks are designed for dry cleaning of fiber optic connector mating sleeves, bulkhead adapters, and receptacles. They are used to clean the end face of connectors already installed in patch panels and hardware devices.

Cleaning procedure:


Before cleaning optical fiber, make sure that the laser source is off.

- Insert the stick into the bulkhead adapter or receptacle.
- Make the tip contact the connector end face.
- Rotate the stick applying a light vertical force.
- Pull the stick out and dispose of it.

Never reuse a stick.


3.6 - Replacement Instructions

The following sections provide instructions for replacing faulty components of the JMA DAS Platform.

 It is important that, before starting work on any equipment, you read the "Safety Rules" on page 108, the general warning statements referenced in each procedure, and the specific warnings in each procedure.

3.6.1 - Replacing Faulty Plug-in Modules

1. Modules managed by the DAS supervision module: Generate an inventory list to store and restore the module current configuration. See the *JMA DAS Platform – Remote Monitoring User Guide* for details.
2. Disconnect all cables (please label all cables before disconnection).
3. Loosen the captive screws that fasten the module to the sub-rack and pull the module out.



4. Insert the new module, sliding it into position carefully.
5. Tighten the captive screws.
6. After replacing optical modules always run a system discovery. See the *JMA DAS Platform – Remote Monitoring User Guide* for details.

3.6.2 - Replacing the ED35TD Fan Unit

The fan unit must be replaced only when the *Fan Speed* alarm occurs. See the "JMA DAS Platform – Remote Monitoring User Guide" for details.

 **Warning**

- ▶ It is important that, before starting work on any equipment, you read the "Safety Rules" on [page 108](#).
- ▶ If the sub-rack is not installed in the rack, place it on a stable surface.

▶  **Hot surface**

Do not touch the surface. Contact with the surface may cause burns. Allow the surface to cool before servicing.

Replacement instructions:

- Tools and equipment:
 - ▶ ED-TFAN-KIT, fan replacement kit for the ED35TD optical transceiver
 - ▶ 3mm hex allen key
- Procedure:

1. Remove the faulty fan unit from the ED35TD sub-rack as follows:

- ▶ Loosen the two captive hexagon socket cylindrical head screws M4x18mm that secure the fan unit to the rear of the sub-rack. Use a 3mm hex allen key.



- ▶ Carefully pull the faulty fan unit out far enough to disconnect the two cables connecting the unit to the board inside the sub-rack.



3 - Procedures

Caution:

Observe due precautions to prevent electrostatic discharge damage.

Disconnect cables gently to prevent damages to the connectors on the board.

2. Install the new fan kit:

- ▶ Connect the two cables from the fan unit to the board inside the sub-rack.
- ▶ Position the fan kit, aligning the fan kit and the sub-rack fixing holes.
NOTE: Make sure the wires are not pinched between the fan kit and the sub-rack.
- ▶ Secure the fan kit to the sub-rack tightening the two captive hexagon socket cylindrical head screws M4x18mm, provided with the replacement kit.

3. Access the Operation and Maintenance software and check that the *Fan Speed* alarm is no longer active for the ED35TD. Refer to the *JMA DAS Platform – Remote Monitoring User Guide* for details.


3.6.3 - Replacing the TDFE Fan Kit

The fan kit must be replaced only when the TDFE *Fan Speed* alarm occurs.

To replace the fan kit, perform the following actions:


1. Extract the TDFE from its sub-rack:

- ▶ Disconnect all cables (please label all cables before disconnection).
- ▶ Loosen the captive screws that fasten the module to the sub-rack and pull the module out.



2. Remove the faulty fan kit:

- ▶ Place the module on a stable surface.
- ▶ Remove the two screws that secure the fan kit to the TDFE heat sink.




TDFE rear view: screws fastening the fan set to the TDFE heat sink

- ▶ Carefully pull the kit forward and downward far enough to disconnect the kit from the TDFE.
- ▶ Set the faulty fan kit aside.

3. Install the new fan kit:

- ▶ Connect the new fan kit to the module.



3 - Procedures

Fan set fixing holes and connector

- ▶ Position the fan kit, aligning the fan kit and the TDFE heat sink fixing holes.
NOTE: Make sure the wires are not pinched between the fans and the heat sink.
- ▶ Fix the fans to the TDFE heat sink inserting the screws, provided with the new kit, through the fixing holes. Tighten the screws.

4. Insert the TDFE back into the sub-rack:

- ▶ Insert the module, sliding it into position carefully.
- ▶ Tighten the module captive screws.
- ▶ Open the TDFE webpage and check that the *Fan Speed* alarm is no longer active.


3.6.4 - Replacing Faulty TPSU/AC-30-1K and TPSU/48-30-1K

This section describes how to replace power supply modules equipped in SUB-PSUN-MU and SUB-PSUN-MU/48 power supply units.


NOTE: Only power supply modules in hot-swappable redundant configuration can be replaced without switching off the system.

To replace the faulty modules, perform the following actions:

1. Unplug the power cable, connected to the faulty module
2. Slide the locking tab on the front panel of the faulty module to the left to unlock the module.
3. Support the bottom of the module with one hand and pull the module out, holding its handle with the other hand.
4. Insert the new module, sliding it into position carefully, until it clicks into place.
5. Connect the power cord to the module.



SUB-PSUN-MU: Replacing faulty TPSU/AC-30-1K power supply modules



SUB-PSUN-MU: Replacing faulty TPSU/AC-30-1K power supply modules

3.6.5 - Replacing Faulty TRPSU/AC-58-1.2k and TRPSU/48-58-2k


This section describes how to replace power supply modules equipped in the JMA remote power distributor.

NOTE: Only power supply modules in hot-swappable redundant configuration can be replaced without switching off the system.


To replace the faulty module, perform the following actions:

1. Remove the faulty module

- ▶ Unplug the power cord providing power supply to the faulty module:




SUB-RPSU2-MU/AC and SUB-RPSU-MU/AC rear view: AC mains sockets



SUB-RPSU2-MU/48 and SUB-RPSU-MU/48 rear view: Vdc inputs

- ▶ Release the securing clip, available at the bottom left corner of the faulty module, to unlock the module front panel.



Remote power supply distribution system: replacing power supply modules

- ▶ Open the power supply front panel to pull the module slightly out.
- ▶ Support the bottom of the module with one hand, then gently pull the power supply all the way out of the chassis with the other hand

2. Install the new power supply module:

3 - Procedures

- ▶ Release the securing clip at the bottom left corner of the new module to unlock the front panel.
- ▶ Slowly insert the new module, sliding it into position carefully, until it is firmly seated.
- ▶ Close the power supply front panel until it clicks into place.
- ▶ Connect the power cord to the module.

4 - Compliance with the Technical Regulatory Standards

4.1 - Compliance with the EU and UK Regulatory Requirements

4.1.1 - EU Directive 2014/53/EU – RED (Radio Equipment Directive) and Radio Equipment Regulations 2017 (S.I. 2017/1206)



The products described in this technical handbook comply with EU directive 2014/53/EU on the harmonization of the laws of the Member States and Radio Equipment Regulations 2017, relating to the making available on the market of radio equipment, when properly installed, maintained, and used for their intended purpose: improving coverage of mobile communication networks.

A signed copy of the Declaration Of Conformity is available upon request.

For further information, contact our after sales department at www.jmawireless.com

Teko Telecom S.r.l. a socio unico

Via Meucci 24/a

40024 Castel San Pietro Terme (Bologna) – Italy

Radio equipment operating frequency bands

Operating bands	Downlink (DL) and Uplink (UL) Operating Frequencies (MHz)
LTE 800	791-821 (DL); 832-862 (UL)
EGSM	925-960 (DL); 880-915 (UL)
RGSM	921-960 (DL); 876-915 (UL)
DCS	1805-1880 (DL); 1710-1785 (UL)
UMTS	2110-2170 (DL); 1920-1980 (UL)
LTE2600	2620-2690 (DL); 2500-2570 (UL)

Maximum radio-frequency power transmitted in the frequency bands

Modular Repeaters (TDFE+TSFE)							
Operating band		LTE 800	EGSM	RGSM	DCS	UMTS	LTE2600
Maximum downlink output power (dBm)	High Power	40	40	40	40	40	40
	Very High Power	43	43	43	43	43	43
Maximum downlink gain (dB)	High Power	90	90	90	90	90	90
	Very High Power	93	93	93	93	93	93
Maximum uplink output power (dBm)	High Power	26	23	23	25	27	26
	Very High Power	26	23	23	25	27	26
Maximum uplink gain (dB)	High Power	90	90	90	90	90	90
	Very High Power	93	93	93	93	93	93

4 - Compliance with the Technical Regulatory Standards

4.1.1.1 - Note Relevant to Product Utilization within the European Union (EU)

Equipment is only for professional use; only adequately trained personnel can operate the equipment. In particular, installation and commissioning must be authorized and carried out by the Mobile Network Operator (MNO) or its authorized representative. The use of the equipment must be in accordance with the MNO.

Depending on the country of utilization, the installation and use of the equipment described in this manual may be subject to restrictions. Users are responsible for verifying compliance with the national provisions or authorization required.

For further information refer to: <http://www.efis.dk/>

	AT	BE	BG	CH	CY	CZ	DE
	DK	EE	EL	ES	FI	FR	HR
	HU	IE	IT	IS	LI	LT	LU
	LV	MT	NL	NO	PL	PT	RO
	SE	SI	SK	TR	UK(NI)		

4.1.1.2 - Compliance with the Maximum Permissible Exposure (MPE) Limits (EN 50385)

Examples of minimum separation distance calculation, based on the EN 50385

The following table summarizes the results of the calculations carried out assuming:

- zero losses between the output connector of JMA equipment and the input connector of the antenna
- maximum gain estimated for outdoor Antenna $G_i = 19\text{dBi}$ (for each band)
- maximum gain estimated for indoor Antenna $G_i = 7\text{dBi}$ (for each band)
- no co-location or operation in conjunction with any other antenna or transmitter.

NOTE: The following table is **not** meant to represent the actual compliance distance from a particular JMA Modular Repeater, being antennas, cables, and other RF components not provided with JMA equipment. The actual compliance distance from a particular equipment can be calculated in the final installation phase only - when antenna, cables and other RF components specifications are available.

Equipment	Type	Maximum Output Power (dBm)	Minimum separation distance between a person and the antenna in order to comply with MPE limits [m]			
			Indoor installation		Outdoor installation	
			E=6 [V/m]	E=20 [V/m]	E=6 [V/m]	E=20 [V/m]
Service Front End (TSFE)	High-power Service Front End (LTE800 or EGSM or DCS or UMTS or LTE2600)	40	6.3	20	25.1	8.0
	Very-high-power Service Front End (LTE800 or EGSM or DCS or UMTS)	43	8.9	2.8	35.6	11.2
Donor Front End (TDFE)	Single-band EGSM Donor Front End	23	0.9	0.3	3.6	1.1
	Single-band DCS Donor Front End	25	1.1	0.4	4.5	1.4
	Single-band LTE 800 or LTE2600 Donor Front End	26	1.3	0.4	5.0	1.6
	Single-band UMTS Donor Front End	27	1.4	0.5	5.6	1.8

4.1.2 - EU Directive 2015/863/EU – RoHS (Restriction of the Use of certain Hazardous Substances)

This product complies with EU Directive 2015/863/EU on Restriction of the use of certain Hazardous Substances in electrical and electronic equipment (also known as “RoHS 3”). The product does not contain the substances listed in the Directive in concentrations higher than the maximum admitted values.



The Environmental Friendly Use Period (EFUP) for all enclosed products and their parts are per the symbol shown here, unless otherwise marked. Certain parts may have a different EFUP (for example, battery modules) and so are marked to reflect such. The Environmental Friendly Use Period is valid only when the product is operated under the conditions defined in the product manual.

4.1.3 - EU Directive 2012/19/EU – WEEE (Waste Electrical and Electronic Equipment)

This product complies with the EU directive 2012/19/EU – WEEE (Waste Electrical and Electronic Equipment)



The symbol of the crossed container marked on the equipment shows that the product, at the end of its useful life, must be collected separately from other refuse. Therefore the user must deliver the equipment that has reached the end of its life to the special differentiated electronic and electrotechnical refuse collection centres for subsequent dispatch of the discarded equipment for recycling, treatment, and environmentally compatible disposal, thus contributing in preventing possible negative effects on the environment and on health and favouring the recycling of the materials from which the equipment is made.

Illicit disposal of the product by the user will lead to the application of the penalties provided for by the national legislations of the various Member States on receipt of directive 2012/19/EU.

For further information, contact our after sales department: www.jmawireless.com

4.1.4 - Packaging and Packaging Waste Directive 94/62/EC and subsequent amendments

The packaging of the product complies with the Directive 94/62/EC and subsequent amendments, concerning packaging and packaging waste. Environmentally harmful materials are not used for packaging.

Packaging is made from materials that can easily be recycled after use. Depending on the means of transportation, the equipment is packed in a cardboard or wooden box, protected with expanded polystyrene or barrier bags.

The packaging materials are marked according to ISO 11 469.

Do not throw packaging materials into unsorted waste. Instead, separate them according to local regulations of waste disposal options.

4.2 - Compliance with FCC Rules and Regulations



All JMA equipment complies with the applicable rules described in Title 47 CFR (Code of Federal Regulations), Part 15.

For further information regarding Supplier's Declaration of Conformity, please contact the representative of responsible party:

Yatin Buch, ybuch@jmawireless.com, Liverpool, New York 13088 USA, Mobile: +1 315-382-3341

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The antenna(s) used for this transmitter must be installed to provide a separation distance from all persons as follows, assuming no co-location or operating in conjunction with any other antenna or transmitter:

- at least 50cm for Donor Front End family (with 12.71dB of maximum antenna gain for operating bands lower than 1.5GHz and 19dB for operating bands higher than 1.5GHz).
- at least 150cm for very-high-power amplifier radio module, equipped inside Service Front End family (with 7.7dB of maximum antenna gain for operating bands lower than 1.5GHz and 11.5dB for operating bands higher than 1.5GHz).
- at least 200cm for very-high-power amplifier radio module in MIMO application, equipped inside Service Front End family (with 7.2dB of maximum antenna gain for operating bands lower than 1.5GHz and 11dB for operating bands higher than 1.5GHz).
- at least 150cm for very-very-high-power amplifier radio module, equipped inside Service Front End family (with 5.4dB of maximum antenna gain for operating bands lower than 1.5GHz and 8.5dB for operating bands higher than 1.5GHz).

4 - Compliance with the Technical Regulatory Standards

- at least 200cm for very-very-high-power amplifier radio module in MIMO application, equipped inside Service Front End family (with 4.9dB of maximum antenna gain for operating bands lower than 1.5GHz and 8dB for operating bands higher than 1.5GHz).

Specifications of antennas, cables, RF components, and similar equipment will be provided only in the final installation phase, being the external antenna not provided with equipment.

4.2.1 - Radio Equipment Operating Frequency Bands: Commercial Bands

Operating bands	Downlink (DL) and Uplink (UL) Operating Frequencies (MHz)
SMR700 Low	728–746 (DL); 698–716 (UL)
SMR700 High	746–758 (DL); 776–788 (UL)
AMPS	869–894 (DL); 824–849 (UL)
PCS	1930–1995 (DL); 1850–1915 (UL)
AWS	2110–2155 (DL); 1710–1755 (UL)

Warning for Commercial Bands

WARNING. This is NOT a CONSUMER device.
It is designed for installation by FCC LICENSEES and QUALIFIED INSTALLERS.
You MUST have an FCC LICENSE or express consent of an FCC Licensee to operate this device.
Unauthorized use may result in significant forfeiture penalties, including penalties in excess of \$100,000 for each continuing violation.

NOTE: Fixed stations operating in the 1710-1755MHz band are limited to 1W EIRP and to a maximum antenna height of 10meters above ground.

4.3 - Industry Canada Compliance



Industry
Canada

Industrie
Canada

▪ Industry Canada

The Radio Standards Specification 102 (RSS-102) sets out the requirements and measurement techniques used to evaluate RF exposure compliance of radiocommunication apparatus designed to be used within the vicinity of the human body.

It is the responsibility of proponents and operators of antenna system installations to ensure that all radiocommunication and broadcasting installations comply at all times with Health Canada's Safety Code 6.

The antenna(s) used for this transmitter must be installed to provide a separation distance from all persons as follows, assuming no co-location or operating in conjunction with any other antenna or transmitter:

- at least 50cm for Donor Front End family (with 15.5dB of maximum antenna gain for operating bands lower than 1.5GHz and 19dB for operating bands higher than 1.5GHz).
- at least 150cm for Very High Power Amplifier radio module, equipped inside Service Front End family (with 8dB of maximum antenna gain for operating bands lower than 1.5GHz and 11.5dB for operating bands higher than 1.5GHz).

Specifications of antennas, cables, RF components, and similar equipment will be provided only in the final installation phase, being the external antenna not provided with equipment.

Equipment will be accessible only to maintenance technicians, who are required to switch it off before performing any maintenance operation.

▪ Industrie Canada

La spécification sur les normes radioélectriques 102 (RSS-102) énonce les exigences et les techniques de mesure utilisées pour évaluer la conformité de l'exposition aux radiofréquences des appareils de radiocommunication conçus pour être utilisés à proximité du corps humain.

Il incombe aux promoteurs et exploitants d'installations de systèmes d'antennes de s'assurer que toutes les installations de radiocommunication et de radiodiffusion respectent tout le temps au code de sécurité 6 de santé du Canada.

La/les antenne (s) utilisée(s) pour ce transmetteur doit être installé afin de fournir une distance de séparation de:

- *Au moins 50cm pour la famille de Front End Donateur (avec 15,5dB de gain maximal d'antenne pour les bandes inférieures à 1,5GHz et 19dB pour les bandes supérieures à 1,5GHz).*
- *Au moins 150cm pour le module amplificateur radio à très haute puissance, équipé à l'intérieur de la famille de Front End de Service (avec 8dB of gain maximal pour les bandes inférieures à 1,5GHz et 11,5dB pour les bandes supérieures à 1,5GHz)*

de toutes les personnes en supposant l'absence de colocalisation ou d'exploitation en conjonction avec une autre antenne ou émetteur.

Spécifications des antennes, câbles, composants à radiofréquence, etc. ne seront fournis que dans la phase finale de l'installation, étant que l'antenne externe n'est pas fourni avec l'équipement.

L'équipement sera accessible seulement aux hommes d'entretien, qui doit l'éteindre avant toutes les opérations de maintenance.

4 - Compliance with the Technical Regulatory Standards

Frequency Band <i>Bande de fréquence</i>	Nominal Passband Gain <i>Gain dans la bande passante nominale</i>	Nominal Bandwidth <i>Largeur de bande nominale</i>	Rated mean output power (single carrier) <i>Puissance de sortie moyenne nominale (porteuse unique)</i>	Input and output impedances <i>Impédances d'entrée et de sortie</i>
Very High Power Amplifier Radio Module				
728-746MHz	48dB	18MHz	43dBm (20W)	50Ω
746-756MHz	48dB	10MHz	43dBm (20W)	50Ω
851-869MHz	48dB	18MHz	43dBm (20W)	50Ω
869-894MHz	48dB	25MHz	43dBm (20W)	50Ω
1930-1995MHz	48dB	65MHz	43dBm (20W)	50Ω
2110-2155MHz	48dB	45MHz	43dBm (20W)	50Ω
2620-2690MHz	48dB	70MHz	43dBm (20W)	50Ω
Digital Front End				
698-716MHz	64dB	18MHz	26dBm (0.4W)	50Ω
777-787MHz	64dB	10MHz	26dBm (0.4W)	50Ω
806-824MHz	64dB	18MHz	26dBm (0.4W)	50Ω
824-849MHz	64dB	25MHz	26dBm (0.4W)	50Ω
1850-1915MHz	64dB	65MHz	26dBm (0.4W)	50Ω
1710-1755MHz	64dB	45MHz	26dBm (0.4W)	50Ω
2500-2570MHz	64dB	70MHz	26dBm (0.4W)	50Ω
798-806MHz	64dB	8MHz	26dBm (0.4W)	50Ω
Six-band Enhanced Power Remote Unit				
728-746MHz	36dB	18MHz	31dBm (1.25W)	50Ω
746-756MHz	36dB	10MHz	31dBm (1.25W)	50Ω
851-869MHz	36dB	18MHz	31dBm (1.25W)	50Ω
869-894MHz	36dB	25MHz	31dBm (1.25W)	50Ω
1930-1995MHz	36dB	65MHz	31dBm (1.25W)	50Ω
2110-2155MHz	36dB	45MHz	31dBm (1.25W)	50Ω
2110-2180MHz	36dB	70MHz	31dBm (1.25W)	50Ω
2350-2360MHz	36dB	10MHz	31dBm (1.25W)	50Ω
2620-2690MHz	36dB	70MHz	31dBm (1.25W)	50Ω
Dual-band Public Safety Enhanced Power Remote Unit				
768-776MHz	36dB	8MHz	31dBm (1.25W)	50Ω
851-869MHz	36dB	18MHz	31dBm (1.25W)	50Ω

Warning: This is not a consumer device. It is designed for installation by an installer approved by an ISED licensee. You **must** have an **ISED licence** or the express consent of an ISED licensee to operate this device.

Avertissement: Ce produit n'est pas un appareil de consommation. Il est conçu pour être installé par un installateur approuvé par un titulaire de licence d'ISDE. Pour utiliser cet appareil, vous **DEVEZ** détenir une **LICENCE d'ISDE** ou avoir obtenu le consentement exprès d'un titulaire de licence autorisé par ISDE.

WARNING. This is NOT a CONSUMER device. It is designed for installation by an installer approved by an ISED licensee. You **MUST** have an ISED LICENCE or the express consent of an ISED licensee to operate this device.

AVERTISSEMENT: Ce produit N'EST PAS un appareil de CONSOMMATION. Il est conçu pour être installé par un installateur approuvé par un titulaire de licence d'ISDE. Pour utiliser cet appareil, vous **DEVEZ** détenir une **LICENCE d'ISDE** ou avoir obtenu le consentement exprès d'un titulaire de licence autorisé par ISDE.

5 - Attachments

5.1 - Getting Help: Technical Support Contact Information

- JMA International
+1 315 431-7100
+1 888-201-6073
customerservice@jmawireless.com
- JMA United States
Toll Free +1 888-201-6073, Outside US +1 315-431-7100
techsupport@jmawireless.com
- JMA Italy - BTC
+39 051 6946811
VAS-techsupport@jmawireless.com

5.2 - Technical Specifications

The following tables provide the electrical, environmental, and mechanical specifications for the JMA DAS Platform components.

Refer to the JMA datasheets for detailed specifications. Contact JMA Sales Office for further information.

Sub-racks

Commercial Code and Description	Dimensions	Operating temperature range	Non-condensing Relative Humidity
SUB-TRX-PSU5N - Standard Active Sub-rack	19" - 3U, depth 270mm (10.63in)	-5°C to +55°C (+23°F to +131°F) with proper forced-air cooling	5%-85% Short period limit (max 96 hours): 5%-93%
SUB-HPOI - Standard Passive Sub-rack	19" - 3U, depth 270mm (10.63in)	-5°C to +55°C (+23°F to +131°F)	
SUB-TRX-PSU-D - Deep Active Sub-rack	19" - 3U, depth 360mm (14.17in)		
TSFE - Service Front End	19" - 2U, depth 360mm (14.17 in)		
ED35TD - Next Generation Optical Transceiver	19" - 1U, depth 330mm (13in)		
TFAN-19-1U-4F-28V - Forced-Air Cooling Unit	19" - 1U, depth 270mm (10.63in)		

Power Supply Components

Commercial Code and Description	Dimensions	Operating temperature range	Non-condensing Relative Humidity	Output Power
TPSU/AC - AC/DC Power Supply Unit TPSU/48 - DC/DC Power Supply Unit	3U - 7TE	-5°C to +55°C (+23°F to +131°F) with proper forced-air cooling	5%-85% Short period limit (max 96 hours): 5%-93%	100W each, up to 2 in parallel 90W each, 3-4 in parallel 80W each, more than 4 in parallel
SUB-PSUN-MU Power supply sub-rack, with one to three AC/DC power supply modules (TPSU/AC-30-1K)	19" - 1U depth 376mm (14.8in) handles included	0°C up to +70°C (+32°F to +158°F) 50 to 60°C, derate 2% /°C 60 to 70°C, derate 2.5%/°C	5%-85% Short period limit (max 96 hours): 5%-93%	900W, each TPSU/AC-30-1K 2430W, max configuration: 3x TPSU/AC-30-1K
SUB-PSUN-MU/48 Power supply sub-rack, with one to three DC/DC power supply modules (TPSU/48-30-1K)	19" - 1U depth 376mm (14.8in) handles included	-5°C up to +55°C (+23°F to +131°F)	5%-85% Short period limit (max 96 hours): 5%-93%	950W each DC/DC module (TPSU/48-30-1K) 2850W, max configuration (3x TPSU/48-30-1K)
SUB-RPSU2-MU/AC, SUB-RPSU-MU/AC Power supply distribution system, with one to four AC/DC power supply modules (TRPSU/AC-58-1.2k)	19" - 2U depth 421.5mm (16.59in)	-5°C up to +55°C (+23°F to +131°F) with proper forced-air cooling	5%-85% Short period limit (max 96 hours): 5%-93%	1.2kW @110-120Vac 1.9kW @200-270Vac each TRPSU/AC-58-1.2k
SUB-RPSU2-MU/48, SUB-RPSU-MU/48 Power supply distribution system, with one to four DC/DC power supply modules (TRPSU/48-58-2k)	19" - 2U depth 421.5mm (16.59in)	-5°C up to +55°C (+23°F to +131°F) with proper forced-air cooling	5%-85% Short period limit (max 96 hours): 5%-93%	1.9kW, each DC/DC Power Supply module (TRPSU/48-58-2k)

5.3 - Safety Rules

Introduction

The equipment described in this technical handbook has been designed and tested in conformity of international safety standards IEC60950/EN60950 and/or IEC62368/EN62368. This equipment must be used under the responsibility of specialised personnel only.

In accordance with IEC60950/EN60950 and/or IEC62368/EN62368, adjustment, maintenance and repair of the exposed equipment shall be carried out only by qualified personnel who are aware of the hazards involved. The minimum qualifications are established in the standard.

Final installation of the systems must fulfill the EMF emission levels, as required by regulations in force.

Safety Precautions

It is essential that both operation personnel and services personnel follow generally accepted safety procedures (IEC60950/EN60950 and/or IEC62368/EN62368) - in addition to the safety precautions specified in this technical handbook - for the correct and safe use of the equipment.

Specific warnings and caution statements, where applicable, can be found throughout this technical handbook.

Warning and caution statements and/or symbols are marked on the equipment where necessary.

Caution: used to indicate the correct operation and maintenance, in order to prevent damage or destruction of equipment or other property.

Warning of danger: used to indicate the potential hazard that requires correct procedures or practices in order to avoid personal injury.

As far as the equipment safety devices are concerned:

- Periodic functional check shall be carried out on protective devices.
- Functional check shall be carried out on protective devices, when they have operated under fault conditions.
- Safety devices shall not be altered or disconnected except for replacement.
- Safety circuits shall not be modified.

Impaired Safety Protection

Whenever it is likely that safe operation is impaired, the equipment must be inoperative and secured against unintended operation.

The appropriate servicing staff authority must be informed.

For instance, the safety is likely to be impaired if the equipment fails to perform the prescribed measurements, or shows visible damages.

Electrostatic Sensitive Devices

Electrostatic sensitive devices (for instance, all ICs and many other semiconductor devices) require correct protection to reduce the risk of personal injury.

Careless handling, during repair, may imply life danger.

When repairing such devices, make sure that you are connected with the same potential as the ground of the equipment by means of the right devices, for example, a GIRDLE (a wrist wrap with resistance) and a WINDING CORD to be connected to the girdle and to the relevant socket placed on the equipment.

5 - Attachments

You must also keep components and tools at this potential.

Electrolytic Capacitors

Non-solid electrolytic capacitors must not contain chemicals, which may be regarded as hazardous if incorrectly handled. Caution is necessary if the outer case is fractured.

Electric Shock

In case of electric shock, do not touch the person before breaking the circuit by means of the power supply switch. If it is not possible to break the circuit power supply, try to rescue the person by means of some insulating materials: for example, a wooden stick, a nylon cord, or a suitable service made of plastic.

NEVER TOUCH ELECTROCUTED PEOPLE WITH YOUR HAND AS LONG AS THEIR BODIES ARE SUBJECTED TO VOLTAGE. IF YOU DO, YOU TOO WOULD BE ELECTROCUTED.

Call the doctor and then immediately perform the artificial respiration as described here below:



Lay the patient on their back with their arms parallel to their body; if the patient lies on an inclined plane, please make sure that their stomach is slightly lower than their breast. Open the patient's mouth and check for the presence of foreign bodies.

Kneel down near the patient at the same level as their head, then put one of your hands under their head and the other one under their neck. Lift the patient's neck and let their head fall backwards as far as possible.

Shift your hand from the patient's neck to their chin; put your thumb between their chin and their mouth, put your forefinger along their jawbone, and keep your other fingers tight. Start the self-oxygenation by deep breathing in standing open-mouthed. With your thumb between the patient's chin and their mouth, keep the patient's lips closed and blow into their nasal cavities.

During these operations see if the patient's breast rises. If not, their nose may be obstructed; in this case, by levering on their chin with your hand, open the patient's mouth, put your lips on and blow into their oral cavity. Look at the patient's breast and see if it rises. One can also use this second method if the patient's nose is not obstructed, as long as their nose be occluded by squeezing their nostrils with your hand after shifting it from their head. The patient's head must be kept bent backwards as far as possible.

Start with 10 fast and deep expirations, then go on at the rhythm of 12 to 15 expirations per minute. Continue as long as the patient has recovered consciousness, or until a doctor has ascertained their death.

5 - Attachments

Burns


As far as burns are concerned:

- Do not try to take off clothes from the burnt parts.
- Pour some cold water on body burnt areas and ask immediately for a doctor.
- Do not apply ointments or oily tinctures.

5.3.1 - Annex

When the equipment or the modules are equipped with the labels shown here below, it is essential to observe the warnings contained:

- Live Voltage Point



- Protective Earthing Terminal

Connect the equipment to the nearest ground reference location, before connecting power supply. The protective earthing terminal can be identified by this symbol:

- Caution! High touch current. Connect to earth before connecting to supply.



- Class 1 Laser Product



Products which are of Class 1 invisible radiation, as defined in the IEC/EN 60825-1:2007 "Safety of laser products - Part 1: Equipment classification, requirements and user's guide".

The product has been classified according to the IEC/EN 60825-1:2007 standard with:

- maximum output of laser radiation: 15mW
- type of emission: continuous
- optical emitted wavelength: 1310nm (second window), 1490-1570 nm (third window)

NOTE: Even if the product is of CLASS 1, please observe the following safety procedures, prescribed in the cited norm:

- do not observe directly the laser beam,
- do not use observation optics (lens, microscopes, telescopes, etc.),
- do not expose eyes directly.

- Hot surface



Warning: Do not touch the surface. Contact with the surface may cause burns. Allow the surface to cool before servicing.

- Devices sensitive to the electrostatics

5 - Attachments



Caution: Please observe due precautions in handling devices which are sensitive to the electrostatics.

- Non-solid electrolytic capacitors may contain chemicals to be regarded as hazardous, if incorrectly handled.



Warning

Maximum caution is required if the outer case is fractured.

5.4 - Warnings and Caution Statements

This section supplements the equipment technical handbook and safety rules, providing a bilingual (English/French) list of the warnings that can be found throughout this technical handbook.

Components

The ED35TD contains a non-replaceable battery so please observe the following precautions:

- During use, storage or transportation of the equipment, the battery cannot be subjected to extreme conditions, such as:
 - An extremely high temperature surrounding environment.
NOTE: The battery allowable temperature range is -40 to +85 °C.
 - An extremely low air pressure.

Exposing the battery to extreme conditions can result in an explosion or the leakage of flammable liquid or gas.

- Disposal of battery into fire or a hot oven, or mechanically crushing or cutting of the battery can result in an explosion.

Installation



Warning

- A correct system installation and setting procedure requires a good knowledge of and experience in installing telecommunication equipment.
- To ensure proper installation and configuration, these activities should be performed by skilled and experienced personnel only.
- Before installing the equipment, carefully read the safety rules attached to this technical handbook. See "[Safety Rules](#)" on page 108.
- Before starting work on any equipment, make sure it is isolated from its power supply source.
- If not approved by JMA, repainting any components of the DAS will void warranty.
- The equipment is intended to be installed in a Restricted Access Location (RAL) where the equipotential bonding has been applied. RAL is defined as a location for equipment where both of the following conditions apply:
 - Access can be gained only by SERVICE PERSONS or by USERS who have been instructed about the reasons for the restrictions applied to the location and about any precautions that shall be taken.
 - Access is through the use of a TOOL or lock and key, or other means of security, and is controlled by the authority responsible for the location.
- In Denmark, Finland, Norway and Sweden, the equipment intended for connection to other equipment or a network shall have a marking stating that the equipment must be connected to an earthed mains socket-outlet.
In Finland: "*Laite on liitettävä suojakoskettimilla varustettuun pistorasiaan*".
In Norway: "*Apparatet må tilkoples jordet stikkontakt*".
In Sweden: "*Apparaten skall anslutas till jordat uttag*".

5 - Attachments

In Denmark: “*Apparatets stikprop skal tilsluttes en stikkontakt med jord, som giver forbindelse til stikproppens jord*”.

- Modular equipment, intended to be housed inside a rack cabinet, must be installed within a protected access area only.

This area must be opportunely protected by security system that will exclude the entry, even if accidental, to unauthorized and untrained personnel. Alternatively, the cabinet, in which the equipment is housed, must be closed on all sides, to allow the access to internal parts to authorized personnel only.

- The equipment is intended to be installed also in an IT power distribution system.

Caution: A cabinet cooling forced air ventilation system, able to provide an air flow of up to 180cfm (5m³/min), is required to ensure cabinet installed equipment proper operation.

Installing Master Units

- Before installing sub-racks inside the cabinet, fasten the cabinet to the site floor, to prevent it from turning over.
- Before installation, make sure that all the components of the system are isolated from the main power supply.

Connections

- Ethernet or coaxial ports that use a shielded cable must be shielded and grounded at both ends.
- Bare conductors must be coated with antioxidant before crimp connections are made.
- Verify that the intra-building port(s) of the equipment or subassembly are suitable for connection to intra-building or unexposed wiring or cabling only. The intra-building port(s) of the equipment or subassembly **must not** have metallic connections to interfaces that connect to the OSP or its wiring. These interfaces are designed for use as intra-building interfaces only (Type 2 or Type 4 ports as described in GR-1089-CORE, Issue 6) and require isolation from the exposed OSP cabling. The addition of primary protectors is insufficient protection for metallic connections between these interfaces and OSP wiring.
- In any event, the installer should never connect an antenna to the master unit *BTS* port.

Optical Connections

Caution: Fiber optic devices are sensitive to static electricity.



When handling fiber optic devices, observe the following precautions:

- Never stare directly into fiber optic connectors and fibers. Invisible emitted laser beams can damage your eyes.
- Always cover optical connectors, adapters, and optical ports with caps to prevent dust from accumulating on the interface. Remove fiber optic protective caps prior to making connections.
- Optical connections must be made with care to avoid damaging the optical fiber or connectors.
- Do not bend fiber optic cable with a tight radius of curvature: the cable might be damaged and losses within the fiber might occur.
- Before mating fiber optic connectors, inspect and clean the connectors and optical ports to ensure optimized performance. Dirty connector interfaces can cause degradation of optical signal.

5 - Attachments

Inspection can be carried out via a fiber optic microscope (optical fiber scope) to detect scratches, dirt, dust, and other contaminants on optical connector end faces.



Before inspection, always turn off the laser source. Never inspect a fiber while looking into it or connecting it to a fiber scope while the laser is on.

Connecting AC and DC Power

- Before starting work on any equipment, make sure it is isolated from its power supply source.
- Make sure that the power supply source provides the nominal voltage prescribed.
- Before making electrical connections ground all active sub-racks equipped in the master unit.
- Equipment shall be connected to an earthed socket-outlet. Earthing connection of the socket-outlet requires verification by a skilled person.

Connecting AC Power

- TPSU/AC-30-1K and Remote Power Supply Distribution System: Since the plug on the power supply cord is intended to serve as the disconnect device, the socket-outlet shall be installed near the equipment and shall be easily accessible.

AC power supply cord requirements

- If it is necessary to fit an AC power supply plug to a power cable, the User must observe the standard wire coloring in the country of installation.

The User must also ensure that the protective earth wire would be the last to break if the cable is subject to excessive strain.

- The detachable AC power supply cord set shall be no lighter than light PVC sheathed flexible cord (H03VV-F) for indoor installation and rubber (H07RN-F) or PVC (SJTW, for the United States and Canada only) for outdoor installation, according to IEC60227, UL 817 for the United States, and CSA C22.2 No.21 for Canada.
- The detachable AC power supply cord set shall comply with the following requirements:
 - nominal voltage 240Vac
 - maximum operating temperature $\geq 60^{\circ}\text{C}$ (140°F)
- For US/Canada market:
 - Minimum cord length is 1.5m.
 - Power supply cords must be no longer than 4.5m, if used in ITE Rooms.
 - Flexible power supply cords must be compatible with Article 400 of the NEC and Tables 11 and 12 of the CEC.
 - Power supply cords for outdoor equipment must be suitable outdoor use type as required by Section 400.4 of the NEC and Rule 4-012 of the CEC, that is, marked water resistant, outdoor, W or W-A.
 - Power supply cords must have attachment plugs rated not less than 125 percent of the rated current of the equipment.

Connecting DC Power

- When installing the DC power supplied equipment, the positive terminal of the DC mains supply must be connected to protective earth, Common DC Return (DC-C) configuration.
- According to the manufacturer, the master unit DC power supply module shall be installed in an isolated secondary circuit, which is separated from primary circuit by Reinforce or Double insulation.
- **TPSU/48:** It is necessary to provide an external protective device from overcurrent (50A, 250V).The protective device should be compliant with the standards of the country of installation.
- **TPSU/48-30-1K**
 - The Vdc input connector is the means to disconnect the equipment from d.c. mains supply. Remove it to disconnect the equipment from power supply source before operation.
 - It is necessary to provide an external protective device from overcurrent (50A, 250V).The protective device should be compliant with the standards of the country of installation.
 - Regarding resistance of earthing conductors, the manufacturer declares that the equipment is tested with 48A of test current for 1 minute, applied between the protective earthing terminal and accessible conductive parts.
 - The ACTRONIC AR35.40.135 power supply filter, or an equivalent type, shall be installed between the equipment Vdc input and the DC power source, in order to achieve compliance with the conducted emission limits.
 - The FAIR-RITE PRODUCTS CORP. model 0431176451 snap ferrite, or an equivalent type, shall be installed near the equipment Vdc input, in order to achieve compliance with the radiated emission limits.
- **Remote Power Supply Distribution System**
 - The Vdc input connector is the means to disconnect the equipment from d.c. mains supply. Remove it to disconnect the equipment from power supply source before operation.
 - It is necessary to provide an external protective device from overcurrent (50A, 250V).The protective device should be compliant with the standards of the country of installation.
 - Regarding resistance of earthing conductors, the manufacturer declares that the equipment is tested with 48A of test current for 1 minute, applied between the protective earthing terminal and accessible conductive parts.
- **ED35TD**
 - The equipment is intended and designed to be connected to a DC power source with a maximum transient voltage up to 1.5kV.
- **DC power supply cord requirements**
 - The color of the wires inside the power cord should be compliant with the standard wire coloring in the country of installation.
 - The detachable DC power supply cord set must meet the requirements for indoor or outdoor use, in accordance with the standards of the country of installation.

5 - Attachments

- ▶ The detachable DC power supply cord set shall comply with the following requirements:
 - nominal voltage 72Vdc
 - maximum operating temperature $\geq 75^{\circ}\text{C}$ (167°F)
- ▶ For US/Canada market:
 - Minimum cord length is 1.5m, with certain constructions (such as external power supplies) allowed to consider both input and output cord lengths into the requirement.
 - Power supply cords must be no longer than 4.5m, if used in ITE Rooms.
 - Flexible power supply cords must be compatible with Article 400 of the NEC and Tables 11 and 12 of the CEC.
 - Power supply cords for outdoor equipment must be suitable outdoor use type as required by Section 400.4 of the NEC and Rule 4-012 of the CEC, that is, marked water resistant, outdoor, W or W-A.
 - Power supply cords must have attachment plugs rated not less than 125 percent of the rated current of the equipment.

▪ Replacement of Faulty Components

- ▶ It is important that, before starting work on any equipment, you read the "Safety Rules" on [page 108](#).

- ▶  **Warning: Hot surface**

The heat sink could reach dangerous temperatures. Do not touch! Contact with the heat sink surface may cause burns. Allow the surface to cool before servicing.

5.5 - Règles de sécurité

Introduction

L'équipement décrit dans ce manuel technique a été conçu et examiné dans la conformité des normes de sécurité internationales IEC60950/EN60950 et/ou IEC62368/EN62368; l'équipement doit être utilisé sous la supervision du personnel spécialisé seulement.

Selon IEC60950/EN60950 et/ou IEC62368/EN62368, l'ajustement, le réglage et la réparation de l'équipement exposé doivent être effectués seulement par le personnel qualifié, qui sont conscients des risques impliqués. Les qualifications minimum sont établies dans la norme.

L'installation finale des systèmes doit satisfaire les niveaux d'émission d'EMF, comme en a été demandé par les règlements en vigueur.

Consignes de sécurité

Pour une utilisation correcte et sûre du dispositif il est très importante que soit le personnel opérante soit le personnel de service suivent les procédures de surété acceptées (IEC60950 / EN60950 et/ou IEC62368/EN62368) en outre aux mesures de sureté indiqués dans le présente manuel technique.

Admonitions spécifiques et avertissements de prudence, si applicables, se trouvent dans ce manuel.

Précaution, Prudence: on l'utilise pour indiquer le fonctionnement et l'entretien correcte afin d'éviter d'endommager ou détruire le dispositif ou autre propriété.

Mises en garde, Admonitions de danger: utilisé pour indiquer une risque potentiel qui demande correctes procédures ou pratiques pour éviter dommages à la personne.

Sur les points nécessaires on a indiqué les symboles qui tirent l'oeil et avertissements de précaution.

En ce qui concerne les dispositifs de sécurité de l'équipement s'il vous plait rappelez-vous cela:

- des contrôles fonctionnels périodiques doivent être effectués sur des dispositifs de protection;
- des contrôles fonctionnels doivent être effectués sur des dispositifs de protection, quand ils ont fonctionné dans des conditions de panne;
- les dispositifs de sécurité ne doivent pas être changés ou déconnectés sauf pour le remplacer;
- le circuit de sécurité ne doit pas être modifié.

Réduite protection de sureté

Dans les cas où le fonctionnement de sureté est probable que a faibli, le dispositif doit être inopérant et le fonctionnement involontaire doit être évité.

On devra informer de ca la direction du personnel de servise du dispositif en objet.

Par exemple, la sureté peut se dire faible dans le cas où les performances du dispositif ne sont pas celles prévues ou bien il présente dommages visibles.

Dispositives sensibles électrostatiques

En cas de dispositives sensibles électrostatiques (par ex. toutes circuits intégrés et plusieurs autres semiconducteurs appartient à ce classe) il est importante d'utiliser la protection apte pour réduire les risques de dommages personnels.

Manoeuvres impropres ou négligents pendant la réparation peuvent comporter un danger mortale.

Pendant la réparation, il faut s'assurer d'être branché avec le meme potential de la mise à sol du dispositif par les dispositives corrects, par ex. une GAINÉ (protection du poignet avec résistance) et un CABLE DE BOBINAGE, à brancher à la gaine et à la prise relative qui se trouve dans le dispositif.

Il faut aussi garder les composants et les outils à ce potentiel.

Condensateurs électrolytiques

Les condensateurs électrolytiques non solides peuvent contenir éléments chimiques qui peuvent être considérés dangereux si manipulés de façon non correcte.

Dans le cas où l'enveloppe extérieur est cassé il est nécessaire d'être prudent.

Fulguration

En cas de fulguration éviter de toucher la personne avant d'avoir coupé le circuit par l'interrupteur de ligne; si ca n'est pas possible, le dégager en employant des matériaux isolants: bâtons de bois, corde de nylon, objets de plastique.

NE PAS TOUCHER LA PERSONNE FOUROYÉE JUSQU'À SON CORP EST SOUS-TENSION: ON PEUT RESTER FOUROYÉ.

Démander l'intervention d'un medecin donc pratiquer promptement la respiration artificielle comme indiqué en suite:



Mettre le blessé sur le dos avec bras parallèle au corps; si le blessé est étendu sur un plan incliné, s'assurer que son estomac est légèrement plus en bas que sa poitrine: Ouvrir la bouche du blessé et contrôler qu'il n'y a pas de corps étrangers.

S'agenouiller près du blessé au niveau de sa tête, mettre une main sous la tête et une sous le cou. Soulever le cou du blessé et en laisser retomber la tête le plus possible à l'arrière.

Déplacer la main du cou au menton du blessé; placer votre pouce entre le menton et la bouche, l'index le long de l'os mâchoire, tenir les autres doigts serrés. Pendant ces opérations commencer l'auto-oxigénéation par de profondes inspirations à bouche ouverte. Avec votre pouce entre menton et bouche du blessé tenir les lèvres serrées et souffler dans la cavité nasale.

Pendant ces opérations contrôler si la poitrine du blessé se soulève. En cas contraire il est possible que le nez est obstrué; alors en faisant pression sur le menton avec la main, ouvrir le plus possible la bouche du blessé, mettre ses lèvres autour et souffler dans la cavité orale. contrôler si la poitrine du blessé se soulève. On peut utiliser cette deuxième méthode au lieu de la première même quand le nez n'est pas obstrué, à condition que il est fermé en serrant les narines avec la main après l'avoir déplacé de la tête. La tête du blessé doit être tenue le plus possible inclinée à l'arrière.

5 - Attachments

Commencer avec dix rapide et profondes expirations, continuer donc au rythme de douze/quinze expiration par minute. Continuer jusqu'à quand le blessé reprend sa connaissance ou un médecin en constate le décès.

Brulures


En ce qui concerne les brulures:

- *Ne pas essayer de détacher les vêtements des parties brûlées.*
- *Verser de l'eau et appeler d'urgence un médecin.*
- *Ne pas appliquer de pommades ou teintures huileuses.*

Annexe

Alors que le dispositif ou les modules sont équipés avec les étiquettes indiquées ci-après, il est très important de suivre les indications indiqués:

- *Partie sous tension*



ATTENTION: connexions à haute tension

- *Extrémité protectrice de mise au sol*

Avant de brancher l'alimentation, branchez l'équipement à l'emplacement au sol le plus proche.

Le terminal de mise au sol peut être identifié par ce symbole:

- *Mise en garde! Courant de contact élevé. Branchez à la terre avant de connecter à la source d'alimentation.*



- *Produit laser de Classe 1*



Les produits qui sont de classe 1 rayonnements invisibles sont définies dans la norme CEI / EN 60825-1:2007 "Sécurité des appareils à laser - Partie 1: Classification des matériels, prescriptions et guide de l'utilisateur".

Le produit a été classifié selon la norme IEC/EN 60825-1:2007 avec:

- production maximale de rayonnement du laser: 15mW
- type d'émission : continu
- longueur d'onde optique émise: 1310nm (deuxième fenêtre), 1490-1570 nm (troisième fenêtre)

Même si le produit est de classe 1, s'il vous plaît respecter les procédures de sécurité suivantes, prévues dans la norme citée:

- ne pas observer directement le faisceau laser,
- ne pas utiliser l'optique d'observation (lentilles, microscopes, télescopes, etc),
- ne pas exposer directement les yeux.

- *Surface chaude*

5 - Attachments



Attention: Ne touchez pas la surface. Le contact avec la surface peut provoquer des brûlure. Laissez la surface refroidir avant tous les travaux d'entretien.

- Dispositives sensibles à l'électrostaticité



ATTENTION: observer les précautions qui s'imposent pendant la manipulation des dispositives sensibles à l'électrostaticité.

- Les condensateurs électrolytiques non solide peuvent contenir elements chimiques dangereux, dans le cas où ils ne sont as traité correctement.



ATTENTION: on demande la précaution maximale dans le cas où l'armoir exterieur presente des fractures.

5.6 - Mises en garde et déclarations de précaution

Ce document complète le manuel technique de l'équipement et les règles de sécurité, fournissant une liste bilingue (anglais / français) des avertissements et de mises en garde qui peuvent être trouvées dans tout ce manuel technique.

Installation



Mise en garde

- L'installation correcte du système et la procédure de réglage exige une bonne connaissance et expérience dans l'installation d'équipements de télécommunication.
- Ces activités doivent être effectuées uniquement par du personnel qualifié.
- Avant d'installer l'équipement, lisez attentivement les règles de sécurité attachées au manuel technique d'équipement. Voir "[Règles de sécurité](#)" on page 117.
- Avant de commencer à travailler sur l'équipement, il doit être isolé du réseau électrique.
- S'il n'est pas approuvé par JMA, repeindre les composants du DAS annulera la garantie.
- L'équipement est destiné à être installé dans un emplacement à accès restreint où une liaison équipotentielle de protection a été appliquée.

Le lieu d'accès restreint est un endroit pour les équipements où les deux conditions suivantes s'appliquent:

- l'accès peut seulement être acquis par des PERSONNES de SERVICE ou par les UTILISATEURS qui ont été instruits sur les raisons des restrictions appliquées à l'emplacement et sur toutes les précautions qui doivent être prises;
 - l'accès se fait par l'utilisation d'un outil ou d'une clé, ou d'autres moyens de sécurité, et est contrôlé par l'autorité chargée de l'emplacement.
- L'équipement modulaire, destinée à être logée à l'intérieur d'une armoire, doit être installé dans une zone à accès protégé seulement.
Cette zone doit être opportunément protégée par le système de sécurité qui exclura l'entrée, même fortuite, à des personnes non autorisées et non formés. Sinon, le cabinet, dans le quel l'équipement est installé, doit être fermé de tous côtés, pour autoriser l'accès aux parties internes au personnel autorisé seulement.
 - L'équipement est destiné pour être installé également dans un système de distribution IT.

Précaution: Un système de refroidissement de l'armoire par ventilation forcé, capable de fournir un flux d'air allant jusqu'à 180cfm (5m³/min), est nécessaire pour assurer le bon fonctionnement du matériel installé dans armoire.

Installation de l'unité principale

- Lors du positionnement des subracks de l'unité principale dans une armoire, fixez l'armoire afin de l'empêcher de se tourner.
- Avant de commencer à travailler sur l'équipement, il doit être isolé du réseau électrique.

Connexions

- Les ports Ethernet / coaxiaux qui utilisent un câblé blindé doivent être blindés et mis à la terre aux deux extrémités.
- Les conducteurs nus doivent être recouverts d'antioxydant avant effectuer les connexions pincées.
- Le port (s) de l'équipement ou sous-ensemble intra-bâtiment est adapté pour le raccordement au câblage intra-bâtiment ou aux fils non exposé ou au câblage seulement. Le port (s) de l'équipement ou sous-ensemble intra-bâtiment ne doit pas être connecté métalliquement aux interfaces connectées au réseau ou à son câblage. Ces interfaces sont conçues pour être utilisées comme interfaces de intra-bâtiment seulement (type 2 ou 4 ports comme décrit dans GR-1089-CORE, numéro 6) et doivent être isolées du câblage OSP exposée. L'ajout de protecteurs primaires n'est pas une protection suffisante pour pouvoir connecter ces interfaces métallique au câblage de l'OSP.
- Dans tous les cas, l'installateur ne doit jamais connecter une antenne à la porte BTS de l'unité principale.

Installation des fibres optiques et des dispositifs aux fibres optiques

- Ne pas observer directement le faisceau laser, ne pas utiliser l'optique d'observation (lentilles, microscopes, télescopes, etc), ne pas exposer directement les yeux.
- Protégez toujours les connecteurs optiques et les adaptateurs avec leur bouchon pour empêcher la poussière de joindre à la face d'extrémité. Retirez les capuchons de protection de la fibre optique juste avant de faire les connexions.
- Avant l'inspection de la fibre, arrêtez toujours la source laser. Alors que le laser est allumé, n'inspectez jamais une fibre en la regardant directement ou en la reliant à un fibroscope.

Alimentation d'énergie

- Avant de faire les connexions électriques, l'équipement doit être isolé du réseau électrique.
- Avant de faire les connexions électriques, branchez à la terre tous les subracks actifs fournis dans l'unité principale.
- L'équipement doit être connecté à une prise de courant reliée à la terre. Mise à la terre de la prise de courant doit être vérifiée par du personnel qualifié.

Alimentation en courant alterné (AC)

- **TPSU/AC-30-1K, SUB-RPSU2-MU/AC, SUB-RPSU-MU/AC,:** Puisque la prise sur la corde d'alimentation d'énergie est prévue pour servir les dispositifs de débranchement, la prise de courant doit être installée près de l'équipement et doit être facilement accessible.

▪ **Cordon d'alimentation AC**

- *S'il est nécessaire de connecter une prise d'alimentation AC à le câble d'alimentation, l'utilisateur doit respecter les codes de couleur de fil standard dans le pays d'installation. L'utilisateur doit également s'assurer que le fil de protection de terre soit le dernier à se rompre si le câble est soumis à une contrainte excessive.*
- *L'ensemble de cordon d'alimentation détachable AC ne doit pas être plus léger que le cordon flexible engainé léger par PVC (H03VV-F) pour une installation à l'intérieur et en caoutchouc (H07RN-F) ou en PVC (SJTW, pour les États-Unis et le Canada uniquement) pour installation à l'extérieur, selon IEC60227, UL 817 pour les États-Unis et CSA C22.2 No.21 pour le Canada.*
- *L'ensemble du cordon d'alimentation détachable AC doit se conformer aux exigences suivantes:*
 - *tension nominale de 240Vac*
 - *température de fonctionnement maximale $\geq 60^{\circ}\text{C}$ (140°F)*
- *Pour les États-Unis et le Canada:*
 - *La longueur minimum du cordon est tenue d'être de 1,5 m.*
 - *Les cordons d'alimentation ne doivent pas dépasser 4,5 m de longueur, s'ils sont utilisés dans les salles d'équipement informatique (ITE).*
 - *Les cordons d'alimentation souples doivent être compatibles avec l'article 400 de la NEC, et les tableaux 11 et 12 de la CEC.*
 - *Les cordons d'alimentation doivent être adaptés à l'utilisation en plein air tel que requis par l'article 400.4 du NEC et par l'article 4-012 de la CEC, marquée résistant à l'eau, en plein air, W ou W-A.*
 - *Les cordes d'alimentation sont exigées d'avoir des prises d'attachements notés au moins 125 pour cent du courant nominal de l'équipement.*

Alimentation en courant continue

- *Lors de l'installation de l'équipement avec alimentation DC, la borne positive d'alimentation DC doit être reliée à la terre dans la configuration Common DC Return (DC-C).*
- *Selon le fabricant, le module d'alimentation DC de l'unité principale doit être installé dans un circuit secondaire isolé qui est séparé de l'unité principale par une isolation renforcée ou double.*
- **TPSU/48:** *Il est nécessaire de prévoir un dispositif de protection externe contre la surintensité (50A, 250V). Le dispositif de protection doit être conforme aux normes du pays d'installation.*
- **TPSU/48-30-1K**
 - *Le connecteur d'entrée Vdc est le moyen de déconnecter l'équipement de l'alimentation électrique du courant continu (d.c.). Retirez-le pour débrancher l'équipement de la source d'alimentation avant l'opération.*
 - *Il est nécessaire de prévoir un dispositif de protection externe contre la surintensité (50A, 250V). Le dispositif de protection doit être conforme aux normes du pays d'installation.*

5 - Attachments

- ▶ *Regarding resistance of earthing conductors, the manufacturer declares that the equipment is tested with 48A of test current for 1 minute, applied between the protective earthing terminal and accessible conductive parts.*
- ▶ *Le filtre d'alimentation ACTRONIC AR35.40.135, ou un type équivalent, doit être installé entre l'équipement Vdc d'entrée et la source de courant continu (DC), afin d'assurer la conformité avec les limites d'émissions réalisées.*
- ▶ *Il faut que la ferrite à clipser FAIR-RITE PRODUCTS CORP. modèle 0431176451, ou un type équivalent, soit placée près de l'input Vdc du composant, afin d'être en conformité avec les limites concernant les émissions rayonnées.*

▪ **SUB-RPSU2-MU/48, SUB-RPSU-MU/48**


- ▶ *Le connecteur d'entrée Vdc est le moyen de déconnecter l'équipement de l'alimentation électrique du courant continu (d.c.). Retirez-le pour débrancher l'équipement de la source d'alimentation avant l'opération.*
- ▶ *Il est nécessaire de prévoir un dispositif de protection externe contre la surintensité (50A, 250V). Le dispositif de protection doit être conforme aux normes du pays d'installation.*
- ▶ *Regarding resistance of earthing conductors, the manufacturer declares that the equipment is tested with 48A of test current for 1 minute, applied between the protective earthing terminal and accessible conductive parts.*

▪ **Cordon d'alimentation DC**

- ▶ *La couleur des fils à l'intérieur du cordon d'alimentation doit être conforme à la couleur de fil standard dans le pays d'installation.*
- ▶ *L'ensemble du cordon d'alimentation amovible DC doit être agréé et en conformité avec les normes de sécurité en vigueur dans le pays d'installation, pour une utilisation en plein air ou en intérieur.*
- ▶ *L'ensemble du cordon d'alimentation amovible DC doit satisfaire aux exigences suivantes:*
 - *tension nominale de 72Vdc*
 - *température de fonctionnement maximale $\geq 75^{\circ}\text{C}$ (167°F)*
- ▶ *Pour les États-Unis et le Canada:*
 - *La longueur minimum du cordon est tenue d'être de 1,5 m, dans certaines constructions les longueurs du fils d'alimentations externes autorisées à l'entrée et à la sortie doivent être considérées dans l'exigence.*
 - *Les cordons d'alimentation ne doivent pas dépasser 4,5 m de longueur, s'ils sont utilisés dans les salles d'équipement informatique (ITE Rooms)*
 - *Les cordons d'alimentation souples doivent être compatibles avec l'article 400 de la NEC, et les tableaux 11 et 12 de la CEC.*
 - *Les cordons d'alimentation doivent être adaptés à l'utilisation en plein air tel que requis par l'article 400.4 du NEC et par l'article 4-012 de la CEC, marquée résistant à l'eau, en plein air, W ou W-A.*
 - *Les cordes d'alimentation sont exigées d'avoir des prises d'attachements notés au moins 125 pour cent du courant nominal de l'équipement.*












▪ **Remplacement des composants**

5 - Attachments

- ▶ *Avant de remplacer des composants, lisez attentivement les règles de sécurité attachées au manuel technique d'équipement. Voir "Règles de sécurité" on page 117.*
- ▶  **Attention: Surface chaude**
*Le dissipateur thermique pourrait atteindre des températures dangereuses. Ne pas toucher!
Le contact avec la surface peut provoquer des brûlure. Laissez la surface refroidir avant tous les travaux d'entretien.*

5.7 - Symbols and Manufacture Labels Affixed to the Product

▪ Symbols

Symbol	Description
	Protective earthing terminal
	Direct Current (DC)
	Alternating Current (AC)
	Live Voltage Point
	Live Voltage Point
	Caution! High touch current. Connect to earth before connecting to supply.
	Class 1 Laser Product
	Hot surface
	Devices sensitive to the electrostatics
	Non-solid electrolytic capacitors
	Caution. Neutral fusing.

▪ **Manufacture Labels**

All products are identified by a bar code label.



The following table provides a description of the bar code label fields.

Field	Description
A	Serial number of the module or equipment
A1	Encoded serial number of the module or equipment
B	Equipment acronym or manufacture part number
B1	Encoded equipment acronym or manufacture part number
C	CF (final test tracing out): when checked certifies that the item has been successfully tested in the Factory Final Test Dept.

Abbreviations

AGC

Automatic Gain Control

BS

Base Station

CPRI

Common Public Radio Interface

DAS

Distributed Antenna System

DE

Digital Electricity

DL

Downlink

EU

European Union

ITE

Information Technology Equipment

LAN

Local Area Network

LMT

Local Maintenance Terminal

LTE-TDD

Time-Division Long-Term Evolution

MU

Master Unit

NEM

Network Element Manager

P2P

Point to Point

Abbreviations

PDU

Power Distribution Unit

PoI

Point of Interface

PSU

Power Supply Unit

RAL

Restricted Access Location

RU

Remote Unit

TDFE

Digital Donor Front End

UK

United Kingdom

UL

Uplink

UPS

Uninterruptible Power Supply

WAN

Wide Area Network

WDM

Wavelength Division Multiplexing